

1962-1972 Suburban Bench

Removal of the seat is recommended for ease of installation.



Step 1. Bottom/B:

Clean the seat thoroughly before installing the seat cover. Be careful detaching the Velcro™ from each other, they are the most fragile part of your seat cover and can be torn off if removed forcibly. Place the seat cover bottom on with the long hook straps to the front and tuck in the long loop Velcro™ sewn on the back edge. Route the hook straps carefully to the back avoiding seat adjustment wire and the heavy seat spring on the left side underneath. Pull on the back edge of the seat cover and use a smoothing motion with your hand from front to back to make sure the cover is pulled back tight into position and work the wrinkles out. With it pulled back, connect the Velcro™. Make sure to line up the seams of the seat cover with the seams of your original upholstery.



Step 2. Bottom/B:

View from behind the driver's side. Route the long one inch wide hook Velcro™ on the left and right side of the seat cover behind the brace for the seat slide and connect it to the rear loop Velcro™ as shown. Keep adjusting the Velcro™ to find the best fit with the least amount of wrinkles.



Step 3. Bottom/B:

Disconnect the Velcro™ to gain grabbing length. Connect the plastic buckle where shown, press the Velcro™ together, trim the excess.



Step 4. Bottom/B:

Snap the metal hook with the hook Velcro™ sewn to it (no slip straps) over the metal edge under the back of the seat and connect the Velcro™ to the rear loop Velcro™. This will keep your seat covers from sliding side ways or forward.



Step 5. Bottom/B:
 Note the areas where Velcro™ are routed and the three silver no slip straps. Note under the driver's side the second Velcro™ in goes between the heavy springs in back of the seat.



Step 6. Top/T:
 Slide the seat cover on with the long extending hook Velcro™ to the front and tuck them into the seat, but don't fasten them yet.



Step 6. Top/T:
 Identify the long side hook Velcro™. Left is the front, right is the rear, and top right is the upper rear Velcro™.



Step 6. Top/T:
 View from under the driver's side. Route the front Velcro™ under the seat to the support spring and connect it to itself as shown.



Step 6. Top/T:
 View from behind the passenger side. Mate the rear and the upper rear Velcro™ as shown. Some adjusting of the Velcro™ may be necessary for the best fit.



Step 6. Top/T:
 Connect the front hook Velcro™ by smoothing one hand down the front of the seat cover, tuck the Velcro™ under the back edge and connect it to the Velcro™ sewn inside the back edge.