

1973-1976 Suburban Bench Installation



Step 1. Bottom/B:

Seat removal is not necessary but very helpful. Carefully disconnect the Velcro on the seat cover. Slide the seat cover on with the long Velcro™ to the front.



Step 2. Bottom/B:

Tuck the back edge of the seat cover into the seat. Line up the seams of the seat cover to the seams of your seat along the front and sides, they should match closely.



Step 3. Bottom/B:

Route the long front Velcro™ under the seat, over the seat slide wire as shown. Press them to the loop Velcro™ sewn on the back edge, trim the excess.



Step 4. Bottom/B:

Route the long side hook Velcro™ on the left and right side, above the seat slide, pressing it to the loop Velcro™ sewn on the back edge. Trim the excess.



Step 5. Bottom/B:

Disconnect the Velcro™ to gain grabbing length. Connect the plastic buckle where shown, press the Velcro™ together, trim the excess.



Step 6. Top/T:

Carefully disconnect the Velcro™ and slide the cover on with the extending hook Velcro™ to the front as shown. Push the Velcro™ thru the seat and connect it to the loop Velcro™ sewn inside the back edge.



Step 7. Top/T:

View from under the side of the seat. Notice the two Velcro™ sewn on each side with the plastic buckle. Connect the front Velcro™ buckle as shown.



Step 8. Top/T:

View from under the back corner of the seat. Connect the rear buckle under the back of the seat as shown. There are two hook 2" X 2" Velcro™ behind each side of the seat. These connect them to the loop Velcro™ on the seat cover "Top" behind the seat.