

1976-91 F-150-450 Bench Seat Installation



Step 1. Prepare the seat for installation:

Using an Allen Wrench or proper sized socket stud, remove the backrest from the set bottom.



Step 2. Bottom/B:

All the parts of the seat cover are labeled on the inside right front corner. Use the "Seat Cover Part ID Chart" to ID parts. Place the bottom on with the long hook (sticky) Velcro™ to the front. Pull the cover around the back corners, then pull it over the front. Work the material inside the seat cover outward, from forefinger to thumb as shown.



Step 3. Bottom/B:

Line up the holes for the side bolts. Line up the seams of the seat cover to the seams of your seat, they should match closely. Line up the seat belt openings.



Step 4. Bottom/B:

Pull the side Velcro™ at an angle, to the back edge and press it onto the loop Velcro™ sewn on the back edge.



Step 5. Bottom/B:
Likewise, pull back and press the rear most Velcro™ to the loop Velcro™ on the back edge.



Step 6. Bottom/B:
Route the long front hook Velcro™ under the seat to the rear loop Velcro™. Make sure to not interfere with the seat slide wire.



Step 7. Bottom/B:
Connect the plastic buckle to the loop on the metal on the outside edge and press the Velcro™ together.



Step 8. Bottom/B:
If the outermost loop of metal isn't working for you, look for another hole into the metal plate (it's farther under the seat, connect it as shown, trim the excess).



Step 9. Bottom/B:
Remove these plastic buckles on the back edge.



Step 10. Bottom/B:
Connect them under the seat where the driver & passenger will be sitting, then press them to the loop Velcro™.



Step 11. Bottom/B:

Bolt the backrest onto the seat bottom, making sure to put the washer between the metal arm and seat cover to prevent wear when moving the seat.



Step 12. Top/T:

Slide the seat cover Top on with the extending hook Velcro™ to the front. Again, line up the seams of the seat cover to the seams of the seat.



Step 13. Top/T:

Manipulate the material inside the seat cover inward to the top, or from middle finger and thumb to pointer finger.



Step 14. Top/T:

Tuck the Velcro™ and seat cover between the metal bar. Use one hand in a smoothing action down the front of the seat cover from top to bottom while pulling on the Velcro™ from behind the seat with the other hand. Tuck the front hook Velcro™ under the back edge and press the Velcro™ together.