

1977-1980 Suburban Bench Seat Installation



Step 1. Bottom: Temporarily remove the two screws on the plastic side panel on both sides using a Phillips screwdriver.



Step 2. Bottom: Temporarily remove the bolts on the left and right using a socket or end wrench.



Step 3. Bottom: Place the seat cover on with the long hook (sticky) Velcro™ to the front. Route them under the seat and connect them to the loop Velcro™ sewn on the back edge, avoiding the seat mechanisms.



Step 4. Bottom: Pull the left and right sides of the seat cover around to the back and mate it to the loop Velcro™ sewn on the back edge as shown.



Step 5. Bottom: After the seat cover is centered left and right, feel for the hole for the side bolts and trim it out with a scissors. The hole can be larger than shown because of the large washer.



Step 6. Bottom: Route the long side hook Velcro™ at an angle, over the seat slide, and then press it to the loop Velcro™ sewn on the back edge.



Step 7. Bottom: Connect the side plastic buckles to framework under the seat, then connect it as shown, trim the excess.



Step 8. Bottom: Fasten the no slip buckle under the back edge of the seat and connect the hook Velcro™ to the loop Velcro™.



Step 9. Bottom: Re-attach the backrest to the seat bottom. Put the side plastic pieces back on.



Step 10. Top: Slide the seat cover top on with the extending hook Velcro™ to the front and tuck them into the seat.



Step 11. Top: Tuck the fabric behind the plastic sides.



Step 12. Top: Slide one hand down the front of the seat and tuck the hook Velcro™ under the back edge and press it to the loop Velcro™ sewn inside the back edge.