

1981-91 S-10-15 Bucket Seat Installation



Step 1. Driver & Passenger Bottom/DB&PB:

All the parts of the seat cover are marked on the underside of the cover. Use the seat cover Part Identification chart to ID parts. Place the seat cover on with the long hook (sticky) Velcro™ to the front. Line the seams of the seat covers to the seams on the seat, they should match closely.



Step 2. Driver & Passenger Bottom/DB&PB:

Tuck the back edge of the seat cover in. Pull it tight from behind the seat, this time concentrate on lining up the front edge.



Step 3. Driver & Passenger Bottom/DB&PB:

Route the long hook Velcro™ under the seat where shown, avoiding the seats slide mechanisms and press them into the loop Velcro™ sewn on the back edge.



Step 4. Driver & Passenger Bottom/DB&PB:

Slide the side hook Velcro™ over the seat slide.



Step 5. Driver & Passenger Bottom/DB&PB:

Tuck the fabric under the plastic cowling on the outside edge of the seat.



Step 6. Driver & Passenger Bottom/DB&PB:

Pull back on the side Velcro's™ while smoothing you hand down the side of the seat cover, then press the hook Velcro™ onto the loop Velcro™ sewn on the back edge. Re-connect and re-tighten the front to back Velcro™ for the best fit.



Step 7. Driver & Passenger Bottom/DB&PB:

Pull the inside edge of material around to the back and press the Velcro's™ together.



Step 8. Driver & Passenger Bottom/DB&PB:

Connect the plastic buckle where shown, or to one of the squiggly support wires in the foam, then back to the rear loop Velcro™. This will help keep the cover from moving around.



Step 9. Driver & Passenger Top/DT&PT:
Slide the covers on with the extending hook Velcro™ to the front.



Step 10. Driver & Passenger Top/DT&PT:
Tuck the cover behind the top of the plastic on the outside of the backrest.



Step 11. Driver & Passenger Top/DT&PT:
Tuck the front of the fabric under the plastic. As in steps 1 & 2, line up the seams of the seat cover to the seams of the seat.



Step 12. Driver & Passenger Top/DT&PT:
Tuck the front hook Velcro™ into the seat and fold the backrest forward. Use one hand in a smoothing action down the front side of the cover from top to bottom while gently pulling the Velcro™ from the back, then press the two together.