

1987-1991 Suburban Bucket Seat Installation



Step 1. Driver and Passenger Bottoms/DB&PB:
All the parts of the seat cover are labeled inside. Use the Seat Cover Part ID sheet to ID parts. Place the covers on with the long hook Velcro™ to the front. Line up the seams of the seat cover to the seats on your seat, they should match closely.



Step 2. Driver and Passenger Bottoms/DB&PB:
Tuck the back edge in.



Step 3. Driver and Passenger Bottoms/DB&PB:
Pull the seat cover back and over the right corner.



Step 4. Driver and Passenger Bottoms/DB&PB:
Same as step 3, pull the back left corner of the seat cover down.



Step 5. Driver and Passenger Bottoms/DB&PB:
Route the side Velcro™ over the top of the seat slide at an angle to the back edge.



Step 6. Driver and Passenger Bottoms/DB&PB:
Press the hook Velcro™ to the loop Velcro™ on the back edge.



Step 7. Driver and Passenger Bottoms/DB&PB:
Route the two long hook Velcro™ under the seat where shown.



Step 8. Driver and Passenger Bottoms/DB&PB:
Connect the hook Velcro™ to the loop Velcro™ on the back edge. Do this by pulling on the back of the seat cover while using one hand in a smoothing action from front to back pulling the seat cover tight, then connect the Velcro™.



Step 9. Driver and Passenger Bottoms/DB&PB:
Connect the two plastic hooks with Velcro™ sewn to them where shown, then press them onto the loop Velcro™.



Step 10. Driver and Passenger Bottoms/DB&PB:
Trim the excess Velcro™. Finished, the Velcro™ should look like this.



Step 11. Driver and Passenger Bottoms/DB&PB:
View from under the seat showing the Velcro™.



Step 12. Driver and Passenger Tops/DT&PT:
Carefully open the seat cover bottom and sides.



Step 13. Driver and Passenger Tops/DT&PT:
Pull the cover down and form it to the top of the seat.



Step 14. Driver and Passenger Tops/DT&PT:
Tuck the seat cover under and behind the armrest.



Step 15. Driver and Passenger Tops/DT&PT:
Connect the vertical Velcro™.



Step 16. Driver and Passenger Tops/DT&PT:
Tuck in the front edge Velcro™.



Step 17. Driver and Passenger Tops/DT&PT:
Pull it through to the back.



Step 18. Driver and Passenger Tops/DT&PT:
Same as Step 8, use one hand in a smoothing action down the front of the seat cover from top to bottom while gently pulling on the Velcro™ from behind, press it to the seat with the front hand, then press it to the loop Velcro™ sewn inside the back edge.



Step 19. Driver and Passenger Armrests/DAL, DAR, PAL, PAR:
Slide the covers on with the opening to the inside.



Step 20. Driver and Passenger Armrests
Form the cover to the front of the armrest making sure it's pulled down all the way.



Step 21. Driver and Passenger Armrests
Make sure the back of the cover is turned inside out.



Step 22. Driver and Passenger Armrests
Using a similar tool shown such as a shoe horn, use the tool to force the cover over the front corner.



Step 23. Driver and Passenger Armrests
Use the tool to pry the cover over the top side of the armrest. This will be very tough to do, as the cover is so tight.



Step 24. Driver and Passenger Armrests
Finished the armrest cover should look like this.