1988-1989 Suburban 40-60 Split Bench



Step 1. Driver & Passenger Bottoms/DB&PB: Place the seat cover on with the long hook Velcro[™] to the front. Tuck in the back edge of the seat cover into the seat.

the inside flaps between the seats. Tilt the

backrest and slide the seat all the way forward.



Step 2. Passenger Bottom/PB: Feed the seat belts through the provided opening. The seams of the seat cover should closely match the seams of your seat.



Step 4. Driver and Passenger Bottoms/DB&PB:
View from behind the driver's seat bottom on the inside. Pull the inside flaps around to the back, tuck it under the plastic, and press the Velcro™ to the loop Velcro™ sewn on the back edge of the seat cover.



Step 5. Driver & Passenger Bottoms/DB&PB: View from the driver's side. Pull the outside flap around to the back and press the hook Velcro[™] to the loop Velcro[™] the same way as step 4.



Step 6. Driver & Passenger Bottoms/DB&PB: View from under the driver's seat. Route the long outside edge hook Velcro[™] next to the seat between the adjustment lever and the tension spring as shown. Press it to the loop Velcro[™] on the back edge.

the back and connect it to the rear loop Velcro[™].





Step 9. Driver & Passenger Bottoms/DB&PB: View from the driver's side. Put the long outside hook Velcro[™] through the square opening in the seat frame and press it to the loop Velcro[™] in back at an angle. This Velcro[™] can be eliminated and cut off if it interferes too much with moving the seat back and forth.



Step 10. Driver & Passenger Bottoms/DB&PB: View from behind the driver's seat. The 1" snap hook clips on to the back edge of the seat with the hook up.



Step 11. Driver & Passenger Bottoms: View from under the driver's seat in back. Clip the 1" snap hook over the metal edge where shown under the back edge of the seat and press the Velcro[™] to the loop Velcro[™] in back. Trim the excess. Use two buckles equally spaced for the passenger side.

Step 12. Driver & Passenger Tops/DT&PT: Slide the seat cover on with the hook Velcro[™] to the front as shown. The seams of the seat cover should closely match the seams of your seat, adjust accordingly. Tuck the hook Velcro[™] into the seat and connect them to the loop Velcro[™] sewn inside the back edge of the seat cover.