

1988-1991 Chevy/GMC Bench with Armrest Installation



Step 1. Top/T:

Slide the Top on with the extending hook Velcro™ to the front, working it down on each side little by little. Form the top of the seat cover to the top of the seat by lining up the seams of the seat to the seams of the seat cover, they should match closely.



Step 2. Top/T:

Pull the cover down all the way, making sure the left and right side seams are lined up as in Step 1. Make sure to poke the lever on the back through the opening provided.



Step 3. Top/T:

Tuck the edges of your cover around the armrest.



Step 4. Top/T:

Take the extending Velcro, along the front, and tuck it in-between the top and bottom.



Step 5. Top/T:

Tilt the backrest forward, and use one hand in a smoothing action down the front of the seat cover. Press the Velcro™ to the seat with the front hand, then press the loop Velcro™ together with the other hand. Work your way across the seat.



Step 6. Armrest/A:

Pull the cover over the arm with the extending Velcro on the bottom. While pulling it on, make sure to follow the seams of the armrest. Tuck the extending Velcro and tuck them behind the armrest and up the back till the Velcro is visible above the arm.



Step 7. Armrest/A:

Once the arm is pulled on, take the encasement flap with the Velcro extending from it and attach it to the Velcro on the inside of the arm.



Step 8. Armrest/A:

Make sure the Velcro is tucked under the cover far enough so that no Velcro is showing.



Step 9. Armrest/A:

Take the extending Velcro from the bottom of the cover and pull them around the material connecting the arm and encasement.



Step 10. Armrest/A:

Take those tiny Velcro and tuck them under the armrest cover as shown, attaching them to the Velcro on the underside.



Step 11. Bottom/B:
Place the cover on with the long hook Velcro™ to the front as shown.



Step 12. Bottom/B:
Tuck the back edge in, lining up the seat belt openings. If your plastic is in good enough condition, you should be able to tuck our cover under the plastic as shown.



Step 13. Bottom/B:
Pull the left and right side around to the back and connect the Velcro™



Step 14. Bottom/B:
Line up the seams of the seat cover to the seams of the seat. Route the front hook Velcro™ above the grey metal bar and seat slide wire as shown.



Step 15. Bottom/B:
Connect the front Velcro™ to the back edge as shown.



Step 16. Bottom/B:
Once the seat is in place, route this outside edge Velcro™ through the opening in the frame as shown.



Step 17. Bottom/B:
Connect it at an angle to the rear loop Velcro™, trim the excess. Reconnect the sides in Step 13 to remove any slack in the sides of the cover.



Step 18. Bottom/B:
Connect the no-slip buckle under the back edge by pressing up hard with one hand, just over the metal edge that's under the foam, then pull back on the Velcro™ with the other hand and it'll click onto it.



Step 19. Bottom/B:
You'll want to place the 3 clips in the same places shown, one left and right and one in the center between the seat belts.



Congratulations!
Your seats are now protected and ready to tackle whatever you have to throw at them.