

1988-1991 Chevy/GMC Bench Seat Installation



Step 1. Top/T:

Slide the Top on with the extending hook Velcro™ to the front, working it down on each side little by little. Form the top of the seat cover to the top of the seat by lining up the seams of the seat to the seams of the seat cover, they should match closely.



Step 2. Top/T:

Pull the cover down all the way, making sure the left and right side seams are lined up as in Step 1. Then tuck the front edge Velcro™ in.



Step 3.Top/T:

Tilt the backrest forward, and use one hand in a smoothing action down the front of the seat cover. Press the Velcro™ to the seat with the front hand, then press the loop Velcro™ together with the other hand. Work your way across the seat. Some readjusting may be necessary.



Step 4. Bottom/B:

Place the cover on with the long hook Velcro™ to the front as shown.



Step 5. Bottom/B:
Tuck the back edge in, lining up the seat belt openings.



Step 6. Bottom/B:
View from behind the driver side bottom. Pull the back edge down as shown.



Step 7. Bottom/B:
Pull the left and right side around to the back and connect the Velcro™



Step 8. Bottom/B:
Route the front hook Velcro™ above the grey metal bar and seat slide wire as shown.



Step 9. Bottom/B:
AS in Step 1 & 2, line up the seams of the seat cover to the seams of the seat. Also, the seat belt openings in the seat cover might be able to be tucked under the plastic if the plastic is in good shape.



Step 10. Bottom/B:
Connect the front Velcro™ to the back edge as shown. Also shown are the anti-slip buckles. See Step 11 for close up on the connection.



Step 11. Bottom/B:

Connect the no-slip buckle under the back edge by pressing up hard with one hand, just over the metal edge that's under the foam, then pull back on the Velcro™ with the other hand and it'll click onto it. Connect it as shown in Step 10, except we've reduce the no-slip clips to 3, one left and right and one in the center between the seat belts. Trim the excess Velcro™



Step 12. Bottom/B:

Connect the front corner buckles same as Step 11, trim the excess.



Step 13. Bottom/B:

Once the seat is in place, route this outside edge Velcro™ through the opening in the frame as shown.



Step 14. Bottom/B:

Connect it at an angle to the rear loop Velcro™, trim the excess. Reconnect the sides in Step 7 to remove any slack in the sides of the cover.