

1992-1994 Suburban Bench Installation



Step 1. Seat Preparation:

Carefully remove the headrests by lifting them up all the way, insert a small allen wrench or heavy wire into the hole in the plastic on one side as shown while holding gentle upward pressure. Once you feel it release, keep holding gentle upward pressure, then go the other piece of plastic and push the metal into the hole in the plastic until it releases. You need to release each side twice. Seat removal is not necessary, but helpful.



Step 2. Top/T:

All the parts of the seat cover are labeled in the inside right corner of each part. Slide the Top on with the extending hook Velcro™ to the front as shown.



Step 3. Top/T:

Tuck the material under the plastic for the headrests.



Step 4. Top/T:

Form the top corners of the seat cover to the seat, folding the material on the inside of the cover as shown from thumb to forefinger. Next, line up the seams of the seat cover to the seams of the seat, they should closely match.



Step 5. Top/T:
Tuck the front edge in and fold the backrest forward.



Step 6. Top/T:
Pull all the Velcro™ thru to the back.



Step 7. Top/T:
Using one hand in a smoothing action down the front of the seat from the top to the bottom, tighten the front of the seat cover. Use the same hand to pin the hook (sticky) Velcro™ to the seat, then press the loop (fuzzy) Velcro™ to it.



Step 8. Bottom/B:
Carefully disconnect the Velcro™ on the seat cover, and place seat cover on with the long hook Velcro™ to the front. Same as Step 4, line up the seams of the seat cover to the seams of the seat, they should closely match.



Step 9. Bottom/B:
Tuck the back edge into the seat.



Step 10. Bottom/B:
Tuck the back loop Velcro™ on top of the seat slide as shown.



Step 11. Bottom/B:
Pull the left and right sides around to the back and connect the Velcro™



Step 12. Bottom/B:
Route the long front hook Velcro™ over the top of the metal bar under the front of the seat as shown.



Step 13. Bottom/B:
Connect them to the loop Velcro™ sewn on the back edge as shown. Tighten the seat cover similar to Step 7, using one hand in a smoothing action from front to back, take up the slack and connect the Velcro™.



Step 14. Bottom/B:
Route this side Velcro™ thru the rectangle opening in the framework after the seat is in its normal place. If connected beforehand, the Velcro™ can be damaged or torn when the seat is slid back into position.



Step 15. Bottom/B:
Again, route the side Velcro™ after the seat is in its normal position.



Step 16. Bottom/B:
Connect these plastic buckles under the seat as shown to the metal frame, then trim the excess.



Step 17. Bottom/B:

Connect these plastic buckles under the front right and left corners of the seat as shown to the metal frame, then trim the excess.



Step 18. Headrests/H:

Carefully open the Velcro™, and slide the cover on with the extending hook Velcro™ to the front.



Step 19. Headrests/H:

Tuck it under the back edge and connect it to the loop Velcro™ sewn inside the back edge.



Step 20. Headrests/H:

Finished it should look like this.