

1992-94 Chevy/GMC 1 & 2 Armrest Bucket Seat Installation



Step 1. Driver & Passenger Bottoms/DB&PB:
All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts. It's not necessary to remove the seats, but it does make the install easier.
Slide the covers on with the extending hook Velcro™ to the front.



Step 2. Driver & Passenger Bottoms/DB&PB:
Work the seam fabric inside the seat cover from forefinger to thumb.
Line up the seams of the seat cover to the seams of the seat on left and right, they should match closely.



Step 3. Driver & Passenger Bottoms/DB&PB:
Pull the inside edge behind the plastic.



Step 4. Driver & Passenger Bottoms/DB&PB:
Pull the inside edge and Velcro™ almost to the screws.



Step 5. Driver & Passenger Bottoms/DB&PB:
Tuck the back inside edge into the seat



Step 6. Driver & Passenger Bottoms/DB&PB:
Pull it down around the corner.



Step 7. Driver & Passenger Bottoms/DB&PB:
Work the outside edge behind the plastic on top.



Step 8. Driver & Passenger Bottoms/DB&PB:
Then, work the fabric into the front of the plastic.



Step 9. Driver & Passenger Bottoms/DB&PB:
Tuck the outside back edge in, but don't fasten it yet.
Again, as in Step 2, line up the seams of the seat cover to the seams of the seat on left and right.



Step 10. Driver & Passenger Bottoms/DB&PB:
Route the inside edge hook (sticky) Velcro™ over the seat slide where shown.



Step 11. Driver & Passenger Bottoms/DB&PB:
Route the outside edge Velcro™ where shown.



Step 12. Driver & Passenger Bottoms/DB&PB:
Route the front edge Velcro™ avoiding the seat mechanisms as shown..



Step 13. Driver & Passenger Bottoms/DB&PB:
Route the outside edge Velcro™ at roughly a 45 degree angle and press them to the carpet on the seat.



Step 14. Driver & Passenger Bottoms/DB&PB:
Pull the back edge of the seat cover over both back corners and pull the cover back, press the Velcro™ to the carpet on the seat.



Step 15. Driver & Passenger Top/DT&PT:
Temporarily remove the access lever using a Phillips screw driver.



Step 16. Driver & Passenger Top/DT&PT:
Carefully open the seat cover and pull it down into position.



Step 17. Driver & Passenger Top/DT&PT:
Work each side down equally when pulling it down



Step 18. Driver & Passenger Top/DT&PT:
Same as Step 2 & 9, center the cover by lining up the seams on left and right. Work the seam fabric inside the cover from thumb to forefinger, or towards the main body.



Step 19. Driver & Passenger Top/DT&PT:
Continue working the seam fabric inward on top.



Step 20. Driver & Passenger Top/DT&PT:
Line up the hole for the access lever.
Note: Suburban, Yukon, and Tahoe do not have these entry levers



Step 21. Driver & Passenger Top/DT&PT:
Re-install the levers.



Step 22. Driver & Passenger Top/DT&PT:
Carefully pull the fabric under the armrest.



Step. 23 Driver & Passenger Top/DT&PT:
Connect the small Velcro™ behind the armrests.



Step 24. Driver & Passenger Top/DT&PT:
Connect the vertical Velcro™ starting on top.



Step 25. Driver & Passenger Top/DT&PT:
Re-connect for to line up material flush for best fit.



Step 26. Driver & Passenger Top/DT&PT:
Tuck the front edge in.



Step 27. Driver & Passenger Top/DT&PT:
Carefully pull the fasteners one by one to the back.



Step 28. Driver & Passenger Top/DT&PT:
Pull on the Velcro™ from behind with one hand while using the other hand in a smoothing action down the front of the seat from top to bottom. Then pin the fastener to the seat with the front hand, and press the seat cover in. Work from one side to the other.



Step 29. Driver & Passenger Armrests/DA&PA:
With the armrest up, carefully slide the cover on.



Step 30. Driver & Passenger Armrests/DA&PA:
Keep pulling the cover down. It will be very tight.



Step 31. Driver & Passenger Armrests/DA&PA:
Work the front inside of the armrest around the corner and fold the armrest down. This will be the toughest. Push the cover over the top of the armrest.



Step 32. Driver & Passenger Armrests/DA&PA:
Use one hand to compress the armrest (left hand), and use the other hand to pull it around the back corner.



Step 33. Driver & Passenger Armrests/DA&PA:
Tuck the hook Velcro™ in by covering it with the top hand while pressing the loop Velcro™ to it.



Step 34. Driver & Passenger Armrests/DA&PA:
Keep working at it until you get the fabric meeting at the back.



Step 34. Lid/L:
Place the lid cover on with the top cut-out to the driver's side. Connect the Velcro™ under the lid. Keep re-tightening the Velcro™ for the best fit.

