

1995-1998 Chevy/GMC Extended Cab Rear Installation



Step 1.

Temporarily remove the headrests by folding the seat ahead and lifting them up all the way. Insert a heavy paper clip or wire into the hole in one side of the plastic while holding gentle upward pressure until it releases. Keep holding upward pressure and release the other side of the headrest.



Step 2. Top/T:

All the parts of the seat cover are labeled inside the cover on the lower right front. Use the seat cover part identification ID chart to ID parts. Slide the seat cover top on with the extending hook (sticky) Velcro™ to the front as shown. Align the seat cover seams to the seams of the seat, they should match closely.



Step 3. Top/T:

Tuck the fabric under the plastic for the headrests. Then, fold the seat top forward and connect the Velcro™ behind the seat. Use one hand in a smoothing action down the front from top to bottom to snug the cover up while connecting the Velcro™.



Step 4. Bottom/B:

Slide the cover on with the extending hook (sticky) Velcro™ to the top side and the hole for the seat lever on the passenger side underneath. Feed the seat lever thru, then pull the cover into position. As in Step 2, align the seams of the cover to the seams of the seat.



Step 5. Bottom/B:

As in Step 3, snug the cover up and connect the Velcro™ with the seat bottom up.



Step 6. Headrest/H:

Slide the headrest covers on with the extending hook Velcro™ to the front. Line up the seams and connect the Velcro™.