

## 1995-2000 Chevy Bench/Bucket W/ Armrest Installation



### Step 1. Driver & Passenger Tops/DT&PT:

First, prepare the seat for installation by temporarily removing the headrests. Lift them up all the way, and then with one hand keep gentle upward pressure between the metal posts, insert a heavy paper clip into the holes in the plastic one side at a time. They will need to be released two times per side



### Step 2. Bottom/B:

Continue preparing the seat for installation by temporarily removing the recline lever on each side of the seat bottom as shown with a Phillips screwdriver. All the parts of the seat cover are labeled inside. Use the Seat Cover Part Identification Chart to identify the different parts of the seat cover.



### Step 3. Bottom/B:

Place the seat cover on with the long hook (sticky) Velcro™ to the front. Feed the seatbelts through the provided opening. The two female ends need to be fed through one at a time as shown.



### Step 4. Bottom/B:

Center the seat cover left and right by lining up the seams of the seat cover to the seams of the seat, they should closely match. Tuck the rear of the seat cover partway in to help hold its position, but not all the way.



**Step 5. Bottom/B:**

Pull the left and right sides around to the back, lining the provided hole for the recline lever. Mate the hook Velcro™ sewn inside the seat cover to the carpet on the back edge of the seat. Re-install the recline levers.



**Step 6. Bottom/B:**

Route the long side hook Velcro™ where shown at an angle, through the square hole in the metal frame, connecting it to the carpet on the back edge of the seat. Sliding your hand down the side of the seat cover from front to back while pulling on the Velcro™ will help remove wrinkles and tighten the side of the seat cover.



**Step 7. Bottom/B:**

Route the long hook Velcro™ between the metal frame and the seat where shown.



**Step 8. Bottom/B:**

Tip the backrests forward and press the hook Velcro™ to the carpet on the back edge of the seat. Do this by using one hand in a smoothing action from front to back while pulling on the Velcro™ from behind, and then press the Velcro™ to the carpet fuzz.



**Step 9. Bottom/B:**

View from behind the passenger side. Lastly, tuck in the rear part of the seat cover, pull back hard pressing the hook Velcro™ sewn inside the seat cover to the carpet on the back edge of the seat.



**Step 10. Driver & Passenger Tops/DT&PT:**

Tip the backrest partway forward and slide the seat covers on with the extending hook Velcro™ to the front.



**Step 11. Driver & Passenger Tops/DT&PT:**

Line up the seams of the seat covers to the seams of the seat, and then tuck the fabric under the plastic for the headrests. Tip the backrest all the way forward and tuck in the hook Velcro™ through to the back.



**Step 12. Driver & Passenger Tops/DT&PT:**

Gently pull on the Velcro™ from behind while using one hand in a smoothing action from top to bottom. Use the front hand to pin the hook Velcro™ to the seat (shown) then touch the back edge of the seat cover to it, connecting the Velcro™.



**Step 13. Headrests/H:**

Slide the headrest covers on with the extending hook Velcro™ to the front, connecting them the loop Velcro™ sewn inside the back edge as shown.



**Step 14. Armrest/A:**

Slide the armrest cover on with the extending hook Velcro™ to the front. Then, fold the armrest flat and connect the Velcro™ at the back of the seat cover.