

# 1995-2000 Tahoe/Yukon/Suburban Middle 60-40 Installation



**Step 1. Driver & Passenger Tops/DT&PT:**  
All the parts of your seat cover are labeled inside. Use the "Seat Cover Piece Identification Chart" to ID parts. Temporarily remove the headrests by depressing the push button release and lifting up.



**Step 2. Driver & Passenger Tops/DT&PT:**  
Slide the seat covers on with the labels DT & PT to the front. Tuck the fabric of the seat cover under the plastic for the headrest. Line up the seams of the seat cover to the seams of your seat, they should closely match.



**Step 3. Driver Top/DT:**  
Tuck the fabric in behind the hinge next the armrest.



**Step 4. Driver Top/DT:**  
Fold the armrest down and tuck the fabric behind.



**Step 5. Driver Top/DT:**  
Fold the armrest up and press the hook Velcro™ to the fuzzy carpet in front of the plastic piece as shown.



**Step 6. Driver & Passenger Tops/DT&PT:**  
Press the front edge of the seat cover to the fuzzy carpet working from one side to the other.



**Step 7. Driver & Passenger Tops/DT&PT:**

Tip the seats flat and press the Velcro™ in back to fuzzy carpet on the seat working from one side to the other.



**Step 8. Driver & Passenger Bottoms/DB&PB:**

Place the seat covers on with the cut-out for the release strap to the back. Line up the seams of the seat cover and press the Velcro™ to the carpet as shown.



**Step 9. Headrests/H:**

Slide the covers on with the extending hook Velcro™ to the front, connecting them to the loop Velcro™ in back.



**Step 10. Armrest/A:**

Slide the armrest cover on with the extending hook Velcro™ to the front. Feed the pull strap from your armrest through the provided opening, line up the seams of the cover, and then connect the fasteners below the seat belt loop on the armrest. Lastly, fold the armrest down and connect the Velcro™ in the back.