

1995-2000 Yukon Buckets Installation



Step 1. Driver & Passenger Tops/DT & PT:

Temporarily remove the headrests by lifting them up all the way. Using gentle upward pressure, insert a heavy paper clip or piece of wire into the hole in the plastic until it releases. Keep holding upward pressure and release the other post. Repeat the procedure until the headrest releases completely.



Step 2. Driver & Passenger Bottoms/DB & PB:

All the pieces of the seat cover are labeled inside. Use the "Seat Cover Piece Identification Chart" to identify the different pieces of the seat cover. Loosen the screws on the plastic seat control panels, but don't remove them, temporarily remove the recline and access levers from the side of the seat.



Step 3. Driver & Passenger Tops/DT & PT:

Open the bottom and inside of the seat cover top and slide it on with the extending hook (sticky) Velcro™ to the front.



Step 4. Driver & Passenger Tops/DT & PT:

Tuck the fabric under the plastic for the headrests.



Step 5. Driver & Passenger Tops/DT & PT:

Tuck this hook Velcro™ under the armrest, and slide the seat all the back.



Step 6. Driver & Passenger Tops/DT & PT:

Connect the Velcro™ under the armrest



Step 7. Driver & Passenger Tops/DT & PT:
Tuck the hook Velcro™ into the seat, slide the seat all the way forward tipping the backrest ahead. Slide your hand down the front of the seat cover in a smoothing action from top to bottom while gently pulling on the Velcro™ from behind to tighten it up.



Step 8. Driver & Passenger Tops/DT & PT:
Once the cover is snug, use your hand to follow the hook Velcro™ to the back (shown), tucking it under the back edge and connecting it to the loop Velcro™ sewn inside. EXT CAB ONLY: Put the access levers back on the outside edge of the backrest.



Step 9. Armrests/A:
Recline the backrests all the way. Slide the armrest covers on with the opening to the inside. They are VERY snug to slide on, so be patient.



Step 10. Armrests/A:
Working from the backseat area, slide your hands around the top of the armrest and work the cover down, making sure its pulled all the way down.



Step 11. Armrests/A:
Pull the back of the armrest cover over and form the cover to the armrest, ling up the seams.



Step 12. Armrests/A:
Connect the Velcro™ at the back of the armrest. Re-connect and tighten them for the best fit.



Step 13. Driver and Passenger Bottoms/DB & PB:
Seats with electric controls: Lift seats up all the way and slide forward. Slide the seat covers with the long extending hook Velcro™ to the front. Tuck the fabric behind the plastic control panel's one corner at a time, starting on the front. Tighten the screws on the panels.



Step 14. Driver and Passenger Bottoms/DB & PB:
Locate the hole provided for the recline lever, feeding the post for the lever through the hole. Install the recline lever onto the seat.



Step 15. Driver and Passenger Bottoms/DB & PB:
Pull on the back edge of the cover and make sure it's all the way back and snug to the front of the seat.



Step 16. Driver and Passenger Bottoms/DB & PB:
Pull the inside edge (next to the console) of the cover back and press it to the carpet on the back of the seat. Next, do the same for the outside edge of the cover.



Step 17. Driver and Passenger Bottoms/DB & PB:
Route the long side hook Velcro™ under the seat, avoiding the mechanisms, at an angle to the back edge to the seat. NOTE: The passenger side doesn't have an



Step 18. Driver and Passenger Bottoms/DB & PB:
press the long side hook Velcro™ in a crossing fashion forming an "X" on the carpet on the back edge of the seat.

outside edge hook Velcro™ if the seat has manual controls.



Step 19. Driver and Passenger Bottoms/DB & PB:
Route the 1" wide long front hook Velcro™ along the outside edge of the seat and press it to the carpet on the back edge of the seat.



Step 20. Driver and Passenger Bottoms/DB & PB:
Route the remaining front hook Velcro™ between the seat and the mechanisms as shown. Be sure the Velcro™ has a straight shot to the back edge.



Step 21. Driver and Passenger Bottoms/DB & PB:
Pull the long hook Velcro™ back and press them to the carpet as shown.



Step 22. Driver and Passenger Bottoms/DB & PB:
Pull the rear edge of the cover back and press the hook Velcro™ sewn inside to the carpet on the seat.



Step 23. Driver and Passenger Bottoms/DB & PB:
With the seat cover in position, everything is covered and looking good.



Step 24. Headrests/H:
Slide the headrest covers on with the long extending hook Velcro™ to the front. Connect them to the loop Velcro™ sewn inside the back edge. Re-install the headrests back into the seat.

