

1995-98 Ford Bench w/ Integral headrests Installation



Step 1. Top/T:

Slide the seat cover on with the extending hook (sticky) fasteners to the front. Line up the seams of the seat cover up to the seams of the seat, they should closely match.



Step 2. Top:

Next, manipulate the fabric from the seams inside the seat cover to the center, from thumb to forefinger on the top of the seat. This will provide a wrinkle free fit.



Step 3. Top:

Manipulate the fabric on the left and right side cap outward, from thumb to forefinger.



Step 4. Top:

Fold the backrest forward; tuck the fabric and fasteners between the seat and the metal bar. Mate the hook fasteners to the loop fastener sewn inside the back edge.



Step 5. Bottom/B:

Place the seat cover on with the long hook fasteners to the front. Work the fabric around the front corners outward, from forefinger to thumb.



Step 6. Bottom:

Tip the backrest ahead pull the rear left and right sides around the back corners, putting the metal piece through the provided hole.



Step 7. Bottom:

Line up the seams of the seat cover to the seams of the seat around the front and sides. Tuck the back edge of the seat cover in, lining up the seatbelt openings, but don't mate the fastener it yet. Route the long hook straps under the front of the seat, between the seat and the seat slide wire.



Step 8. Bottom:

Mate the long hook fasteners to the carpet on the back edge of the seat



Step 9 Bottom:

Make sure the fabric is tucked behind the plastic arm on the sides of the seat. Carefully route the two rear most side hook fasteners around the metal bar as shown and mate them to the carpet on the back edge of the seat.



Step 10 Bottom:

Route the furthest forward side fastener through the slot in the seat slide and mate it to the carpet on the back edge of the seat. Pull on the back edge of the seat cover, line up the slots for the seatbelts, and mate the hook fastener sewn inside the back edge to the carpet on the back edge of the seat.



Step 10 Bottom:

Note: This is not a picture of the actual seat. Attach the side plastic buckle under the seat to the metal frame or support wire, then back to itself, trim off excess.