1997-2002 Jeep Wrangler Bucket Installation



Step 1. Driver & Passenger Tops/DT&PT:
The parts of the seat cover are marked inside. Use the seat cover "Piece Identification Chart" to identify the parts. Slide the seat cover with the extending hook (sticky) Velcro™ to the front.



**Step 2. Driver & Passenger Tops/DT&PT:** Locate the seat release strap and feed it through provided opening.



**Step 3. Driver & Passenger Tops/DT&PT:**Work the fabric from the seam inside the seat cover from thumb to forefinger, forming the seat cover to the top of the seat.



**Step 4. Driver & Passenger Tops/DT&PT:**Connect the Velcro<sup>™</sup> below the seat release lever behind the seat on the outside edge.



Step 5. Driver & Passenger Tops/DT&PT: Tuck the hook Velcro™ into the seat.



Step 6. Driver & Passenger Tops/DT&PT:
Pull on the Velcro™ from behind with one hand while using the other hand in a smoothing action down the front of the seat cover from top to bottom. Tuck the Velcro™ under the back edge and connect them to the loop Velcro™ sewn inside.



Step 7. Driver & Passenger Bottoms/DB&PB:
Slide the seat cover on with the long hook Velcro™ to the front, and put the recline lever through the provided opening.



**Step 8. Driver & Passenger Bottoms/DB&PB:** Work the fabric from the seam outward, from forefinger to thumb.



**Step 9. Driver & Passenger Bottoms/DB&PB:** Tuck in the back edge of the seat cover.



Step 10. Driver & Passenger Bottoms/DB&PB:
Pull the left and right sides around to the back and connect them to the corresponding loop Velcro™.



Step 11. Driver & Passenger Bottoms/DB&PB:
Route the long hook Velcro™ under the front of the seat as shown connecting them to the loop Velcro™ in back. Route the inside edge hook Velcro™ as shown.



Step 12. Driver & Passenger Bottoms/DB&PB: Slide the outside edge hook Velcro™ where shown, between the seat slide and the seat frame.



Step 13. Driver & Passenger Bottoms/DB&PB:

Press the hook Velcro™ sewn on the inside edge of the seat to the carpet on the seat.



**Step 14. Driver & Passenger Bottoms/DB&PB:**Clip two of the no-slip plastic hooks to the wires that go from side to side under the back of the seat, and then press them to the loop Velcro™ in back.