

1999-2001 Ford F-250-F550 Buckets



Step 1. Driver and Passenger Bottoms/DB&PB:
All the parts/pieces of the seat cover are labeled inside the cover. Use the Seat Cover Piece Identification chart to ID parts. Place the seat cover on with the long hook (sticky) Velcro™ to the front.



Step 2. Driver and Passenger Bottoms/DB&PB:
View from the driver's side. Slide the long outside edge hook Velcro™ between the plastic and the seat where shown. Do this using one hand to pry the plastic away from the seat and push it down with the other hand. Loosening the screw behind the recline lever will give you more room.



Step 3. Driver and Passenger Bottoms/DB&PB:
View from the passenger side. The long outside hook Velcro™ route at an angle between the floor and the seat slide and fasten at an angle to the fuzzy carpet on the back edge of the seat bottom.



Step 4. Driver and Passenger Bottoms/DB&PB:
View from under the passenger bottom inside under the seat belts. Route the inside hook Velcro™ at an angle where shown to the fuzzy carpet on the back edge of the seat bottom.



Step 5. Driver and Passenger Bottoms/DB&PB:
Push the small extending hook Velcro™ into the seat and press it to the carpet on the seat. If a longer piece is sewn to it, slide it thru between the seat and frame and press it to the carpet on the back edge.



Step 6. Driver and Passenger Bottoms/DB&PB:
Press the hook Velcro™ to the carpet on the sides of the seat in front and behind the seat belts as shown.



Step 7. Driver and Passenger Tops/DT&PT:
Carefully open the seat cover and slide the cover on with the extending Velcro™ to the front and the opening for the armrest on the inside. Align the seat cover seams to the seams of the seat and connect the Velcro™ under the armrest.



Step 8. Driver and Passenger Tops/DT&PT:
Tuck the extending hook Velcro™ into the seat and connect them to the loop Velcro™ sewn inside the back of the seat cover. The best way to tighten the seat cover is slide one hand down the front of the seat in a smoothing action from top to bottom while gently pulling on the front edge Velcro™ from behind the seat, pinning it to the seat, then pressing the loop Velcro™ to it.



Step 9. Driver & Passenger Armrests/DA&PA:
Slide the armrest cover on with the cut-out on the inside. They will be tight going on.



Step 10. Driver & Passenger Armrests/DA&PA:
Work the top of the armrest cover down all the way. Fold the seams inside of the cover (where my forefinger is) to the middle (where my thumb is)



Step 11. Driver & Passenger Armrests/DA&PA:
Connect the Velcro™ behind the armrest.



Step 12. Lid/L:
Place the lid cover on by positioning the cut-out in front for the clipboard, then mating the Velcro™ under the lid as shown. Some repositioning and tightening of the Velcro™ may be needed to get it tight.