

1999-07 F-250-550 Bench w/ Integral headrests Installation



Step 1. Top/T:

Slide the seat cover on with the extending hook (sticky) Velcro™ to the front. Line up the seams of the seat cover up to the seams of the seat, they should closely match.



Step 2. Top/T:

Next, manipulate the fabric from the seams inside the seat cover to the center, from thumb to forefinger on the top of the seat. This will provide a wrinkle free fit.



Step 3. Top/T:

Fold the backrest forward and tuck the hook fasteners into the seat. Use one hand in smoothing action down the front of the cover from top to bottom, and then press the hook Velcro™ to the loop Velcro™ sewn inside the back edge.



Step 4. Bottom/B:

Place the seat cover on with the long hook Velcro™ to the front and feed the seatbelts through the provided openings.



Step 5. Bottom/B:

First pull the driver's side around to the back and mate the Velcro™ to the carpet, then do the passenger side. **Regular cabs:** have no carpet, so precede to Step 6.



Step 6. Bottom/B:

Line up the seams of the seat cover to the seams of the seat around the front and sides. Tuck the back edge of the seat cover in, lining up the seatbelt openings, but don't connect the Velcro™ yet.



Step 7. Bottom/B:

Route the long side hook Velcro™ where shown at an angle, pressing them to the carpet on the back edge of the seat.

Regular cabs: connect the side Velcro™ to the loop Velcro™ sewn on the back edge. Also connect the side flaps to the loop Velcro™ sewn on the back edge.



Step 8. Bottom/B:

With the seams lined up, press the hook Velcro™ under the knees to the carpet on the seat and route the long hook Velcro™ under the front of the seat, between the seat and the seat slide bar.



Step. 9 Bottom/B:

Press the long hook Velcro™ to the carpet on the back edge of the seat.

Regular cabs: connect the Velcro™ to the loop Velcro™ on the back edge of the seat cover (not shown).



Step. 10 Bottom/B:

Lastly, pull back on the rear most part of the cover and mate the 2" wide hook Velcro™ sewn inside to the carpet on the back edge of the seat, moving from one side to the other.

Regular cabs: connect the plastic hooks with hook Velcro™ sewn to them under the back edge of the seat to the plastic edge that holds on the original upholstery. Lastly, connect the hook Velcro™ on the plastic hooks to the loop Velcro™ sewn on the back edge. The will anchor the seat cover bottom in place.