

## 2001-07 F-250-350 Buckets w/ integral seatbelt Installation



### Step 1. Driver and Passenger Tops/DT & PT:

Temporarily remove the headrests by lifting them up all the way. Then with slight upward pressure, simultaneously depress the two push button releases until the headrest comes out. One push button release is easily seen (pointer finger), and one is slightly hidden (pinkie).



### Step 2. Driver and Passenger Tops/DT & PT:

The pieces of the seat cover are labeled inside. Use the "Seat Cover Piece Identification Chart" to identify the parts of your seat cover. Slide the seat cover on with the extending hook (sticky) Velcro™ to the front and tuck it behind the shoulder mounted seatbelt, and the armrest.



### Step 3. Driver and Passenger Tops/DT & PT::

Tuck the fabric under the plastic for the headrests and the shoulder mounted seatbelt.



### Step 4. Driver and Passenger Top/DT & PT:s:

Connect the Velcro™ behind the plastic seatbelt box on top of the seat.



### Step 5. Driver and Passenger Tops/DT & PT::

Connect the Velcro™ behind the armrest, and down the inside.



### Step 6. Driver and Passenger Tops/DT & PT::

Connect the vertical Velcro™ starting on top.



**Step 7. Driver and Passenger Tops/DT & PT::**

Work your way down to the bottom a few inches at a time using some downward force on both pieces. This may take a few tries to get the seam lined up and remove any wrinkles on the outside edge. Now, line up the seams of the seat cover to the seams of the seat, they should closely match.



**Step 8. Driver and Passenger Tops/DT & PT::**

Use one hand in a smoothing action down the front from top to bottom, while gently pulling on the Velcro™ from the back. Then, tuck the hook Velcro™ into the seat, using one hand to pin the Velcro™ to the seat, and then touch the back part of the seat cover to it. You may have to re-connect the fasteners a few times to get the best fit.



**Step 9. Driver and Passenger Bottoms/DB & PB:**

Place the seat covers on with the long hook Velcro™ to the front. Tuck the back edge of the seat cover in behind the plastic cowlings.



**Step 10. Driver and Passenger Bottoms/DB & PB:**

Work the fabric inside the seat cover towards the outside edge (from forefinger to thumb). Line up the seams of the seat cover to the seams of the seat.



**Step 11. Driver and Passenger Bottoms/DB &PB:**

Route the long hook Velcro™ under the front of the seat and connect them to the carpet on the back edge of the seat. For seats with electric controls, lift the seat up. Be sure to route the Velcro™ between the seat and the moving metal framework (shown) allowing the seat to move freely. Use caution reaching under the seat to avoid sharp metal edges.



**Step 12. Driver and Passenger Bottoms/DB &PB:**

Tuck the two long inside edge hook Velcro™ down and under the seat. Route them carefully to the back edge of the seat and press them to the carpet on the seat. Some re-positioning of the Velcro™ may be needed for the best fit.



**Step 13. Driver and Passenger Bottoms/DB &PB:**

Route the front long outside edge hook Velcro™ where shown, avoiding the seats mechanisms, and press it to the carpet on the back edge of the seat. See step 14 for proper Velcro™ positions.



**Step 14. Driver and Passenger Bottoms/DB &PB:**

Tuck the outside edge rear hook Velcro™ into the seat, avoiding mechanisms, and press it to the carpet on the back edge of the seat. Note the correct angles and positions of the Velcro™.



**Step 15. Driver and Passenger Bottoms/DB &PB:**  
Lastly, pull on the back edge of the seat cover with one hand and use the other hand in a smoothing action from front to back, taking up the slack in the seat cover, and then press the Velcro™ to the carpet on the back edge of the seat.



**Step 16. Headrests/H:**  
Open the headrest cover and slide it on one side with the extending hook Velcro™ to the front. Form it to the corner as close as you can. The seams of the cover should closely match the seams of your headrest.



**Step 17. Headrests:**  
Compress the headrest against a table and pull the other side down. The headrest will spring back into shape once the headrest cover is in position.



**Step 18. Headrests:**  
Work the fabric inside the headrest cover outward (from forefinger to thumb).



**Step 19. Headrests:**

Connect the small side Velcro™ first, and then connect the front hook Velcro™.



**Step 20. Lid/L:**

First, tuck the fabric under the notebook clip.



**Step 21. Lid/L:**

Connect the corresponding Velcro™ under the lid as shown. It will be a little tough at first to get it in place until you start connecting some Velcro™. Fasten a few, then the rest, and then re-tighten them all one by one.



**Step 22. Driver and Passenger Armrest/DA&PA:**

Recline the seats and slide the cover on with the opening towards the seat, pull it all the way down forming it to the front of the armrest with both hands.



**Step 23. Driver and Passenger Armrest/DA&PA:**

Connect the Velcro™ behind the armrest.



**Step 24. Driver and Passenger Armrest/DA&PA:**

The material should be flush when you're done.