

2002-05 Dodge 40-20-40 Non-opening Middle Bottom Installation



Step 1. Driver and Passenger Bottoms DB/PB:
Use the "Seat Cover Piece Identification Chart" to identify the different parts of the seat cover. Temporarily remove the recline lever using a Phillips screwdriver.



Step 2. Driver and Passenger Bottoms:
Slide the seat cover over the upholstered flap on the outside, then position the cut outs for the recline lever. Note, this model seat doesn't have electric controls on the driver seat. Pull the outside edge of the seat cover back lining up the hole for the recline lever and press the hook (sticky) Velcro™ to the loop Velcro™ sewn on the back edge of the seat cover, then put the lever back on. A cordless drill works great for this, just be careful, don't cross thread it.



Step 3. Driver and Passenger Bottoms:
Route the long hook Velcro™ under the front of the seat and stick them to the loop Velcro™ sewn on the back edge of the seat cover. Next, pull the inside edge of the seat cover (next to the center console) around to the back and connect the hook Velcro™ to the loop Velcro™ sewn on the back edge of the seat cover.



Step 4. Driver and Passenger Bottoms:
Route the long inside and outside hook Velcro™ to the carpet on the back edge of the seat. Next, tuck the back edge of the seat cover into the seat, pull back, and press the hook Velcro™ to the loop Velcro™ sewn on the back of the seat cover. Connect the plastic buckles under the back of the seat to the rear foam support wire, then back to the loop Velcro™ on the back edge of the seat cover, trim the excess. Move the seat in all directions after installing to make sure the seat's action is not interfered with. Adjust the Velcro™ if needed to free the seats action or smooth out any wrinkles.



Step 5. Driver and Passenger Tops/ DT & PT:

Temporarily remove the headrests by depressing the push button release, gently and evenly lifting up. Slide the seat cover on with the extending hook straps to the front. Tuck the seat cover under the plastic for the headrest starting with the push button release.



Step 6. Driver and Passenger Tops:

Tuck the hook Velcro™ into the seat. Line up the seams of the seat cover to the seams of your seat, they should closely match. Gently pull on the hook Velcro™ with one hand from behind while sliding your other hand down the front of the seat cover taking up the slack in the seat cover. Lastly, connect the hook Velcro™ to the loop Velcro™ sewn inside the back edge.



Step 7. Console/C:

Tuck the hook Velcro™ into the seat. Line up the seams of the seat cover to the seams of your seat, they should closely match. Gently pull on the hook Velcro™ with one hand from behind while sliding your other hand down the front of the seat cover taking up the slack in the seat cover. Lastly, connect the hook Velcro™ to the loop Velcro™ sewn inside the back edge.



Step 8. Console:

Do not apply a fabric protecting agent like Armourall to the inside of the console. Clean the surface with rubbing alcohol. Scrub the plastic hard with rubbing alcohol and wipe it dry when it's still wet. Peel off the backing and stick the adhesive Velcro™ to the plastic on the inside of the box, not on the top. If they are not sticking, stop and re-clean the areas. The adhesive hook Velcro™ works best at 68 degrees or warmer for at least 24 hrs if possible.



Step 9. Lid/L:

Connect the Velcro™ under the console lid starting with the top or front. The small rear Velcro™ slide into the hinge in back or bottom. Reposition the straps for the proper fit. Slide the loop Velcro™ under the back of the console cover and press the Velcro™ together.



Step 10. Middle Bottom/ MB:

Temporarily remove the seatbelt from its elastic restraint. Place the seat cover on with the long hook Velcro™ to the front.



Step 11. Middle Bottom:

Pull the left and right sides of the seat cover around to the back and press them to the carpet on the seat, or the seat cover if it doesn't have carpet. Route the long hook Velcro™ under the front of the seat and connect them to the carpet. Route the long side hook Velcro™ under the seat and connect them at an angle to the carpet forming an "X" in the middle as shown.



Step 12. Middle Bottom:

Press the back edge to the carpet as shown. Put the seatbelts through the elastic restraints sewn to the seat cover. On regular cabs with no carpet on the seat, press the hook Velcro™ to the loop Velcro™ sewn on the back side of the seat cover.



Step 14. Headrests/H:

Slide the headrest cover on with the hook Velcro™ to the front, compressing the headrest to get the cover on. The headrest will relax back to its original shape once the cover is pulled all the way down.



Step 15. Headrests:

Tuck the hook Velcro™ under the back edge and connect them to the loop Velcro™ sewn inside.