

2002-2005 Dodge 40-20-40 Non-opening Middle Bottom with Non-opening Armrest Installation



Step 1. Driver and Passenger Bottoms DB/PB:
Use the "Seat Cover Piece Identification Chart" to identify the different parts of the seat cover. Temporarily remove the recline lever using a Phillips screwdriver.




Step 2. Driver and Passenger Bottoms:
Slide the seat cover over the upholstered flap on the outside, then position the hole for the recline lever and put it back on. Note: Your style of seat does NOT have electric controls like the picture shows.

Tuck in the back edge of the seat cover. Line up the seams of the seat cover to the seams of your seat around the front and sides, they should match closely.

Pull the outside edge of the seat cover back trying to not bind the material around the recline lever, then press the hook (sticky) Velcro™ to the carpet on the back edge of the seat, and then put the lever back on.



Step 3. Driver and Passenger Bottoms:
Route the long hook Velcro™ under the front of the seat and press them to the carpet on the back edge of the seat. Next, pull the inside edge of the seat cover (next to the center console) around to the back and press the hook Velcro™ to the carpet on the back edge of the seat. Notice the left and right sides are high enough to leave 3/4" of carpet showing under them. This leaves space for the back edge hook Velcro™.



Step 4. Driver and Passenger Bottoms:
Route the long inside and outside hook Velcro™ to the carpet on the back edge at an angle. Next, tuck the back edge of the seat cover into the seat, pull back, and press the hook Velcro™ to the carpet on the back of the seat. Move the seat in all directions after installing to make sure the seat action is not interfered with. Adjust the Velcro™ if needed.



Step 5. Driver and Passenger Tops/ DT & PT:
Temporarily remove the headrests by reclining the backrests and depressing the push button release (shown), while gently and evenly lifting up. Slide the seat cover on with the extending hook Velcro™ to the front. Tuck the seat cover under the plastic for the headrest starting with the push button release.



Step 6. Driver and Passenger Tops:
Tuck the hook Velcro™ into the seat. Line up the seams of the seat cover to the seams of your seat, they should closely match. Gently pull on the hook Velcro™ with one hand from behind the seat while sliding your other hand down the front of the seat cover taking up the slack in the seat cover. Lastly, connect the hook Velcro™ to the loop Velcro™ sewn inside the back edge.



Step 7. Armrest/A:
Carefully open and slide the cover on with the extending hook Velcro™ to the front as shown.



Step 8. Armrest/A:
Fold the Armrest down, tuck the hook Velcro™ thru to the back.



Step 9. Armrest/A:
Pull the Velcro™ tight, tuck it under the back edge and connect the Velcro™ as shown.



Step 10. Middle Bottom/ MB:
Temporarily remove the seatbelt from its elastic restraint. Place the seat cover on with the long hook Velcro™ to the front.



Step 11. Middle Bottom:

Pull the left and right sides of the seat cover around to the back and press them to the carpet on the seat, or the seat cover if it doesn't have carpet. Route the long hook Velcro™ under the front of the seat and connect them to the carpet. Route the long side hook Velcro™ under the seat and connect them at an angle to the carpet forming an "X" in the middle as shown.



Step 12. Middle Bottom:

Press the back edge to the carpet as shown. Put the seatbelts through the elastic restraints sewn to the seat cover. On regular cabs with no carpet on the seat, press the hook Velcro™ to the loop Velcro™ sewn on the back side of the seat cover.



Step 14. Headrests/H:

Slide the headrest cover on with the hook Velcro™ to the front, compressing the headrest to get the cover on. The headrest will relax back to its original shape once the cover is pulled all the way down.



Step 15. Headrests:

Tuck the hook Velcro™ under the back edge and connect them to the loop Velcro™ sewn inside.