

2003-2007 Chevy 40-20-40 Non-opening/folding Console Install



Step 1. Driver & Passenger Tops/DT & PT

Temporarily remove the headrests by lifting it up all the way and inserting a heavy paper clip into the holes in the plastic as shown. Do this one at a time, gently lifting up and holding pressure until the headrest releases.

The pieces of the seat cover are labeled inside the seat cover. Use the "Seat Cover Piece Identification Chart" to identify the different pieces of the seat cover.



Step 2. Driver & Passenger Tops/DT & PT

Carefully open the seat cover top and slide the seat cover on with the long hook Velcro™ to the front. Lean into the vehicle and pull the inside of the cover next to the console all the way down. Next, tuck the fabric under the plastic for the headrests.



Step 3. Driver & Passenger Tops/DT & PT:

Tuck the fabric under the plastic for the shoulder mounted seatbelt using a sawing motion to start, and then carefully use a thin metal object like a feeler gauge or a flat screwdriver to finish tucking the material.



Step 4. Driver & Passenger Tops/DT & PT:

Hold the top part in place with one hand and then connect the vertical Velcro™ with the other.



Step 5. Driver & Passenger Tops/DT & PT:

Connect the vertical Velcro™ using a bear hug method starting at the top working your way down a few inches at a time.



Step 6. Driver & Passenger Tops/DT & PT:

Line up the seams of the seat cover to the seams of the seat, they should closely match. Next, tilt the backrest forward and tuck the extending hook (sticky) Velcro™ into the seat.



Step 7. Driver and Passenger Tops/DT & PT:

Gently pull the Velcro™ from behind the seat with one hand while using your other hand in a smoothing action in front of the seat from top to bottom. Tuck the Velcro™ under the back edge and starting on the inside and work your way out.



Step 8. Driver and Passenger Bottom/DB & PB:

Place the seat cover bottoms on with the long hook Velcro™ to the front.



Step 9. Driver and Passenger Bottom/DB & PB:
Work the material from the seam inside the seat cover from the inside to the outside edge (thumbs to fingers). Line up the seams of the seat cover to the seams of your seat, they should closely match. Tuck in the back edge and pull it back but don't fasten it yet.



Step 10. Driver and Passenger Bottom/DB & PB:
Use caution when reaching under the seat and avoid sharp metal edges. Move the seat forward, tip the backrest ahead. If you have electric seats be sure to lift the seat up as high as it will go. This will pull everything away from your seat and free up some space. With the seat cover pulled back into position, route the long hook Velcro™ under the front of the seat, avoiding any seat mechanisms, and press them to the carpet on the back edge of the seat. Route the long inside edge hook Velcro™ at an angle to the back and press them to the carpet on the seat.



Step 11. Driver and Passenger Bottom/DB & PB:
Slide the outside edge hook Velcro™ up between the seat and the plastic. Carefully reach under the seat for the Velcro™ and mate it at an angle to the carpet on the back edge



Step 12. Driver and Passenger Bottoms:
View of under the front of the driver's seat. Push the plastic hook over the seat brace as shown, pull it tight, press the Velcro™ together, trimming the excess.



Step 13. Driver and Passenger Bottom/DB & PB:
Slide the seat all the way forward and pull back on the cover, smoothing it along the sides of the seat from front to back, pressing the hook Velcro™ sewn inside to the carpet on the seat.



Step 14. Headrests/H:
Compress the headrest and squeeze the cover on with the extending hook Velcro™ to the front using the corner of a table. Connect the hook Velcro™ to the loop Velcro™ in back.



Step 15. Middle Top/MT:
Slide the cover on with the extending hook Velcro™ to the front, again lining up the seams. Tuck the hook Velcro™ in and connect them to the loop Velcro™ inside the back edge.



Step 16. Middle Bottom/MB:
Slide the driver and passenger seats all the way forward and tilt the backrests ahead. Place the cover on with the extending hook Velcro™ to the front. Tuck the cover behind the plastic drink holders and line up the seams along the front and sides.



Step 17. Middle Bottom/MB:
Route the front hook Velcro™ under the seat, mating them to the carpet on back of the seat. Pull the left and right sides back and press them onto the carpet.



Step 18. Middle Bottom/MB:
Route the side Velcro™ at an angle to the carpet in back, and then tuck in the rear edge of the cover and pull back, connecting it to the carpet.