

2003-2007 Suburban 60-40 Middle Installation



Step 1. Headrests/H:

All the parts of the seat cover are labeled inside the cover on the inside right front corner. Use the "Seat Cover Part ID Chart" to identify parts. Slide the headrest covers on while the headrest is still on the seat. Lift the headrest up all the way. While keeping gentle upward pressure, push a small Allen Wrench into the hole in the plastic on each headrest post until the headrest comes out.



Step 2. Step 1. Headrests/H:

Line up the seams of the seat cover to the seams of the seat, they should match closely. Tuck the front hook (sticky) Velcro™ under the back edge and connect it to the loop (fuzzy) Velcro as shown.



Step 3. Driver & Passenger Bottoms/DB&PB:

Place the cover on with the opening for the seat release strap to the back. Feed the strap through the provided opening. Again, line up the seams of the seat cover to the seams on the seat, they should match closely.



Step 4. Driver & Passenger Bottoms/DB&PB:

Press the hook Velcro™ to the carpet fuzz under the seat as shown.



Step 5. Driver Bottom/DB:

Press the hook Velcro™ sewn inside the seat cover in the area of the seatbelts on the back edge to the carpet on the seat.



Step 6. Driver & Passenger Tops/DT&PT:

Carefully open the inside edge Velcro™ and slide the seat cover on with the extending hook Velcro™ to the front and the 1" wide strip turned inside out as shown.



Step 7. Driver Top/DT:

Open the Velcro™ for the armrest



Step 8. Driver Top/DT:

Tuck the fabric under the armrest, and tuck it behind the plastic hinge (pointer finger indicating it).



Step 9. Driver Top/DT:

Connect the Velcro at the back of the armrest cavity.



Step 10. Driver & Passenger Tops/DT&PT:

Tuck the material under the plastic for the headrests.



Step 11. Driver Top/DT:
Tuck the fabric under the should seatbelt.



Step 12. Driver Top/DT:
Connect the Velcro down the inside edge, starting at the top, working your way to the bottom a few inches at a time.



Step 13. Driver & Passenger Tops/DT&PT:
Press the back edge Hook Velcro™ to the fuzz just about the hinge on the backside of the seat.



Step 14. Driver & Passenger Tops/DT&PT:
Line up the hole provided for the latch. Latch the cargo flap to the backside of the seat.



Step 15. Driver & Passenger Tops/DT&PT:
Using one hand in a smoothing action down the front of the seat while gently pulling on the front hook Velcro™, then press it to the fuzz on the Cargo Flap as shown.



Step 16. Driver & Passenger Cargo Flaps/DCF&PCF:
Turn the cover inside out so the hook Velcro™ doesn't stick to the carpet fuzz. Pull all the way down and press the hook Velcro™ to the carpet fuzz next to the hinge.



Step 17. Armrest/A:

Place the cover on with the extending hook Velcro™ to the front, and feed the factory pull strap through the provided opening.



Step 18. Armrest/A:

Fold the armrest down and tuck the front hook Velcro™ through to the back. Connect it to the loop Velcro™ on the back edge