2005-09 Dodge Bucket Seats w/ plastic sides Installation



Step 1. Driver & Passenger Bottoms/DB&PB:

All of the parts of your seat cover are labeled on the inside. Use the "Seat Cover Piece Identification Chart" to identify the pieces. Place the seat cover on with the long hook (sticky) fasteners to the front. Line up the seams of the seat cover to the seams of the seat, they should closely match. Route the hook fasteners under the front of the seat, avoiding any seat mechanisms, and mate them to the carpet on the back edge as shown.



Step 2. Driver & Passenger Bottoms/DB&PB:

Slide the outside edge hook fastener down between the plastic cowling and the seat. Look under the front of seat to locate it, and then route it at an angle, avoiding mechanisms, and mate it to the carpet on the back edge. The inside edge hook fastener mates similarly at an angle.



Step 3. Driver & Passenger Bottoms/DB&PB:

Tuck in the back edge of the seat cover and tilt the back rest forward.



Step 4. Driver & Passenger Bottoms/DB&PB:

From the behind the seat, pull back on the cover and mate the hook fastener to the carpet as shown. Move the seat in all directions to be sure the seats action is not impeded. Some repositioning of the fasteners may be necessary for fit and to allow the seat to move freely.



Step 5. Driver & Passenger Bottoms/DB&PB:

The seat cover should cover the fasteners and the carpet once centered.



Step 6. Driver & Passenger Tops/DT&PT:

Temporarily remove the headrests by depressing the push button release and gently lifting up. Slide the seat cover on with the extending hook straps to the front. Tuck the seat cover under the plastic for the headrest starting with the push button release.



Step 7. Driver & Passenger Tops/DT&PT:

Tuck the hook straps into the seat. Line up the seams of the seat cover to the seams of your seat, they should closely match. Gently pull on the hook strap with one hand from the back while sliding your other hand down the front of the seat cover in a smoothing action. Lastly, tuck the fasteners under the back edge and mate the hook fastener to the loop fastener sewn inside.



Step 8. Headrests/H:

Slide the cover on with the extending hook straps to the front. Line up the seams of the cover to the seams of the headrests. Mate the hook fasteners to the loop fastener in back as shown.



Step 9. Lid/L:

View of lid removed from truck (removal is not necessary for install) . Connect the Velcro $^{\text{\tiny M}}$ under the lid as shown.