2005-2011 Dakota Bucket Seat Installation




Step 1. Headrests/H: All the parts of the seat cover are labeled on the inside front right of each part. Use the seat cover part ID chart to identify the parts. Slide the headrest cover on with the extending hook Velcro[™] to the front while the headrest is still on the seat.



Step 2. Headrests/H: Work the fabric inside the seat cover from the sides, to the front, or from forefinger to thumb as shown. Line up the seams of the seat cover to the seams on the headrest, they should match closely.







Step 4. Headrests/H: Tuck the front hook (sticky) Velcro[™] under the back edge and connect it with the loop (fuzzy) Velcro[™] sewn inside the back edge as shown.



Step 5. Driver & Passenger seats: Using a Phillips screwdriver and remove the recline lever and set it aside.



Step 6. Driver & Passenger Top/DT&PT: Slide the seat cover on with the extending hook Velcro[™] to the front as shown.



Step 7. Driver & Passenger Top/DT&PT: Tuck the fabric under the plastic for the headrests starting with the push button side first.



Step 9. Driver & Passenger Top/DT&PT: Gently pull on the Velcro[™] from behind the seat with one hand while using the other hand to smooth the seat cover from top to bottom. The use the front hand to pin the Velcro[™] to the seat, then press the Velcro[™] together.



Step 8. Driver & Passenger Top/DT&PT: Tuck the extending hook Velcro[™] into the seat. Again, line up the seams of the seat cover to the seams of the seat, same as Step 2.



Step 10. Driver & Passenger Bottom/DB&PB: Slide the seat cover bottom on as shown. Tuck in the back edge and pull the cover back into position. Again, same as Step 2 & 8, line up the seams of the seat cover to the seams of the seat, they should match closely.



Step 11. Driver & Passenger Bottom/DB&PB: Pull the outside edge of the seat cover around to the back and press the hook Velcro[™] to the carpet on the back edge of the seat, making sure to line up the hole for the recline lever.



Step 12. Driver & Passenger Bottom/DB&PB: Pull the inside around to the back and press the hook Velcro[™] to the carpet as shown.





Step 13. Driver & Passenger Bottom/DB&PB: Put the recline lever back onto the seat.





Step 15. Driver & Passenger Bottom/DB&PB: Fold the long front hook Velcro in half lengthwise to stiffen it up. Route them to the back edge and connect them to the carpet on the back edge. Lastly, pull the back edge of the seat cover back and press the hook Velcro[™] to the carpet fuzz.



Step 16. Console Lid/L: Connect the Velcro[™] under the lid as shown.