2007-2014 Suburban 3rd Row 50-50 Installation Instructions



Step 1. Driver & Passenger Bottom/DB&PB:

All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID the parts. Remove the seats from the vehicle. Tuck the rope that's sewn inside the front edge behind the plastic cowling.



Step 2. Driver & Passenger Bottom/DB&PB:

Pull the outside edge around and press the hook (sticky) Velcro™ to the carpet on the back edge of the seat.



Step 3. Driver & Passenger Bottom/DB&PB:

Tuck the side behind the plastic cowling as in Step 1.



Step 4. Driver & Passenger Bottom/DB&PB:

Push the hook Velcro[™] to the carpet on the side of the seat.



Step 5. Driver & Passenger Bottom/DB&PB:

Tuck in the back edge. Line up the seams of the seat cover to the seams of the seat, they should match closely.



Step 6. Driver & Passenger Bottom/DB&PB:

Pull the cover back and press the hook Velcro™ to the carpet on the back of the seat bottom.



Step 7. Headrest removal:

Temporarily remove the headrests by lifting them up all the way, and inserting a heavy paper clip or chunk of coat hanger wire into the holes in the plastic while holding gentle upward pressure.



Step 9. Driver & Passenger Top/DT&PT:

Open the seat cover and slide it behind the seat belts as shown with the extending hook Velcro™ to the front.



Step 8. Headrest/H

Slide the headrest covers on with the extending hook $Velcro^{TM}$ to the front. Line up the seams, and tuck the $Velcro^{TM}$ under the back edge and mate it to the loop (fuzzy) $Velcro^{TM}$ sewn inside the back edge.



Step 10. Driver & Passenger Top/DT&PT: Tuck the seat cover behind the plastic for the headrests.



Step 11. Driver & Passenger Top/DT&PT: Tuck in the small part of the front edge.



Step 12. Driver & Passenger Top/DT&PT:Tuck the cover in around the side plastic and form it to the corner.



Step 13. Driver & Passenger Top/DT&PT:Temporarily loosen the Phillips screws for the seat belt.



Step 14. Driver & Passenger Top/DT&PT: Tuck the seat cover under the plastic and mate the Velcro™.



Step 15. Driver & Passenger Top/DT&PT:
Pull the 1" hook Velcro™ through to the back and mate it to the carpet on the back of the seat.



Step 16. Driver & Passenger Top/DT&PT:Form the sides of the seat cover to the seat by aligning the seams as in Step 5. Manipulate the material inside the seat cover from forefinger to thumb.



Step 17. Driver & Passenger Top/DT&PT: Mate the side Velcro™ starting at the top.



Step 18. Driver & Passenger Top/DT&PT: Use two hands to pull the material together.



Step 19. Driver & Passenger Top/DT&PT: Continue to the bottom. reconnect the Velcro™ for the best fit.



Step 20. Driver & Passenger Top/DT&PT:
Press the hook Velcro™ onto the carpet on the seat back.



Step 21. Driver & Passenger Top/DT&PT: Tuck the Velcro™ into the seat.



Step 22. Driver & Passenger Top/DT&PT:
Fasten the Velcro™ by using one hand in a smoothing action down the front of the cover from top to bottom while pulling on the Velcro™ from the back, pin it to the seat with the front hand, and press the loop Velcro™ sewn inside the back edge.