

2007-2014 Suburban 2nd row 60-40 Installation



Step 1. Driver & Passenger Top/DT&PT:
Temporarily remove the headrests by gently lifting up while depressing the push button release, then insert a metal coat hanger sized metal wire into the hole in the other piece of plastic until it releases.
All the parts of the seat cover are labeled inside.
Use the seat cover piece identification chart to ID parts.



Step 2. Headrests/S:
Slide the covers on with the extending hook (sticky) Velcro™ to the front. Connect them to the loop (fuzzy) Velcro™ sewn inside the back edge.



Step 3. Driver & passenger Bottoms/DB&PB:
Pull the seat cover on with the long Velcro™ to the front.



Step 4. Driver & passenger Bottoms/DB&PB:
Pull the inside edge around and tuck it behind the plastic.



Step 5. Driver & passenger Bottoms/DB&PB:
Tuck the outside edges of the seat cover behind the plastic cowl.



Step 6. Driver & passenger Bottoms/DB&PB:
Route the front hook Velcro™ under the front of the seats.



Step 7. Driver & passenger Bottoms/DB&PB:
Connect them to the carpet on the back edge of the seat.



Step 8. Driver & passenger Bottoms/DB&PB:
Pull the rear part of the seat cover back and connect it to the carpet on the back edge of the seat.



Step 9. Driver Top/DT:
Very careful opening the inside edge of the seat cover. Place the cover on with the extending hook Velcro™ to the front. Fold the armrest out and tuck the seat cover around it.



Step 10. Driver Top/DT:
Line up the seams of the seat cover to the seams of the seat, they should closely match. Tuck the fabric behind the plastic on the left side.



Step 11. Driver Top/DT:
Next, tuck the seat cover under the armrest.



Step 12. Driver Top/DT:
Tuck both side in and clear of the hinge area.



Step 13. Driver & Passenger Tops/DT&PT:
Tuck the extending hook Velcro™ into the seat.



Step 14. Driver & Passenger Tops/DT&PT:
Tuck the fabric under the plastic for the headrests.



Step 15. Driver Top/DT:
Tuck the fabric under the plastic for the seat belt, then connect the Velcro™ at the top.



Step 16. Driver Top/DT:
Continue working your way down using the "Bear Hug" method shown.



Step 17. Driver & Passenger Tops/DT&PT:
Fold the seat flat and pull the left and right corners around to the back and press the hook Velcro™ to the carpet on the back edge of the seat.



Step 18. Driver & Passenger Tops/DT&PT:
Slide one hand down the front of the seat in a smoothing action from top to bottom while gently pulling on the Velcro™ from the back, then press them to the carpet on the seat back.



Step 19. Driver & Passenger Tops/DT&PT:
Connect the hook Velcro™ on the back of the seat, starting on one side working to the other.



Step 20. Armrest-Console/A:
Feed the factory armrest pull tab through the cover and tuck the front edge behind the plastic for the drink holders.



Step 21. Armrest-Console/A:
Tuck the fabric under the back side one corner at a time.



Step 22. Armrest-Console/A:
Tuck the front edge in and fold the armrest down



Step 23. Armrest-Console/A:
Connect the Velcro™ at the back of the armrest.