## **2008-2010 F-250, 350, & 450 Front Bucket Seat Installation**



Step 1. Lid/L:

All the pieces of the seat cover are marked inside. Refer to the "Seat Cover Piece Identification Chart" to identify pieces. Place the lid cover on with the letter "L" marked inside to the back. Connect the front to back Velcro™ first, and then the side to side Velcro™.



Step 2. Driver & Passenger Tops/DT & PT:

Slide the seat covers on with the extending hook Velcro™ to the front. Align the seams of the seat covers to the seams of your seat, they should closely match.



Step 3. Driver & Passenger Tops/DT & PT:

Using both hands in a smoothing action, work the seat cover down snugly into position, lining the seams of the seat cover to the seams of the integral headrest. Lean into the truck and grab the bottom inside edge of the seat cover next to the console and pull it down, then do the outside edge. This will help to fit the seat cover to the shoulders of seat.



Step 4. Driver & Passenger Tops/DT & PT:

Tip the backrest forward and tuck the hook Velcro™ through to the back. Slide one hand down the front of the seat in a smoothing action from top to bottom while gently pulling on the Velcro™ from behind. Connect the hook Velcro™ to the loop Velcro™ in back starting on one side, moving to the other.



Step 5. Driver and Passenger Bottom/DB & PB: Place the seat covers on with the long 2" wide hook Velcro™ to the front. Pull the cover back into position and tuck in the back edge in but don't fasten it to the carpet yet. As in Step 2, line up the seams of the seat cover to the seams of the seat.



Step 6. Driver and Passenger Bottom/DB & PB:
Pull the inside part of the seat cover next to the center
console around to the back and press the hook
Velcro™ sewn inside the seat cover to the carpet on
the back edge of the seat.



Step 7. Driver and Passenger Bottom/DB & PB: If the seats have electric controls, lift the seat all the way up towards the roof and forward. Slide the outside edge hook Velcro™ where shown between the seat and the plastic cowling.



Step 8. Driver and Passenger Bottom/DB & PB: Route the outside edge hook Velcro™ between the metal frame and the seat mechanisms as shown and press it to the carpet on the back edge of the seat. Fasten the inside edge hook Velcro™ the same way.



Step 9. Driver and Passenger Bottom/DB & PB: View from behind the driver's seat, bottom left. Tilt the backrest ahead and feed the short rear most outside edge hook Velcro™ around the back corner of the seat and press it to the carpet on the seat.



Step 10. Driver and Passenger Bottom/DB & PB:
Route the long hook Velcro™ under the front of the seat, avoiding the seat's mechanisms, pressing them to the carpet on the back edge of the seat. Lastly, pull back firmly on the back edge of the seat cover and press the hook Velcro™ sewn to the carpet on the back edge of the seat.