

2009-10 F-150 Super Crew rear 60-40 w/armrest Installation



Step 1. Driver & Passenger Bottoms/DB&PB:
All the parts of the seat cover are labeled inside. Use the seat cover Piece Identification Chart to ID parts. Using the seat release lever, lift the seat bottom partway up. Slide the seat cover on with the cut-out for the seat release to the bottom as shown.



Step 2. Driver & Passenger Bottoms/DB&PB:
Pull the cover down on the left and right sides by kneeling over each side, gripping the top and bottom and pulling down. Line up the seams of the seat cover to the seams of the seat, they should closely match. Manipulate the seat cover material inside the cover to the middle from thumb to forefinger as shown.



Step 3. Driver & Passenger Bottoms/DB&PB:
Fold the seat down and tuck in the extending hook (sticky) Velcro™ in, lining up the opening for the center seatbelt



Step 4. Driver & Passenger Bottoms/DB&PB:
Use one hand in a smoothing action on the top of the seat from front to back while gently pulling on the Velcro™ from the bottom. Press the Velcro™ onto the carpet on the underside of the seat as shown.



Step 5. Driver & Passenger Bottoms/DB&PB:
Press the inside edge Velcro™ to the carpet under the seat bottoms as shown. The passenger side fastens differently than the driver's side.



Step 6. Driver & Passenger Bottoms/DB&PB:
Press the Velcro™ shown to the bottom of the seat by pulling down and pressing the Velcro™ onto the carpet, starting on one side, moving to the other.



Step 7. NEW INSTALL Driver & Passenger Top/DT&PT: Instructions for releasing the top of the backrests from the back wall of the truck. This make the installation of the DT & PT a lot easier. Lift the seat bottoms up, feel for the silver latch (being pointed to) behind the top of the seat on the outside edge (location is shown on the back wall in Step 9). Use a gloved hand to move the silver latch up, it's pretty tough on the finger or thumb. The silver latch must be moved up (towards the pointer finger)to the open position as shown to release the backrest. If you're not able to get the seat to release call us at 877-485-3001 for more instructions. If you don't want to try to release the backrests, skip down to Step 11.



Step 8. Driver & Passenger Top/DT&PT: Carefully disconnect the Velcro™ on the bottom edge. Tuck the fabric under the plastic for the headrests starting with the push button release first. Line up the seams of the seat cover to the seams of the seat on the left and right side, they should closely match. Tuck in the front edge of the seat cover and long hook Velcro™. **DRIVER TOP INSTALLATION:** Follow instructions Step 8-15 after releasing the backrest from the back wall.



Step 9. Driver & Passenger Top/DT&PT: Route the two long front hook Velcro™ around to the side and press them to the seat holding them tight. Tighten the seat cover by using one hand in a smoothing action down the front of the seat cover from top to bottom while pulling on the bottom edge of the seat cover with the other hand. Use the bottom hand to pin the material to the seat, then reconnect the Velcro™ tighter to remove any slack on the front side.



Step 10. Driver & Passenger Top/DT&PT: Make sure the wall bracket looks like the picture with the sliding rod down about an inch. Then, with the seat bottoms up, push the backrest onto the back wall until you hear a click from the latch. Pull forward on the seat top to make sure the latch is secured. If it's not connected, reposition the rod on the wall bracket and keep trying to click it in. It may take a few attempts.



Step 11. Driver & Passenger Top/DT&PT:

Temporarily remove the headrests by lifting them up all the way, pushing the two release buttons at the same time while gently lifting up.



Step 12. Driver & Passenger Top/DT&PT:

Lift the seat bottoms up a little, then slide the seat cover over the top of the seat. **Driver's side:** tuck the cover behind the seatbelt and poke the armrest through the provided opening.



Step 13. Driver & Passenger Top/DT&PT:

Tuck the fabric under the plastic for the headrests starting with the push button release first. Line up the seams of the seat cover to the seams of the seat on the left and right side, they should closely match.



Step 14. Driver Top/DT:

Line up the armrest cavity seams on left and right, and press the two hook Velcro™ sewn inside the cover to the carpet inside the armrest cavity.



Step 15. Driver Top/DT:

Push the fabric in under the armrest, then press the Velcro™ onto the carpet on the back of the armrest cavity, just past the plastic on the bottom side.



Step 16. Driver Top/DT:

Lastly, tuck the rear part of the armrest cavity in behind the armrest, pressing the Velcro™ to the carpet on the back of the armrest cavity.



Step 17. Driver Top/DT:

Form the top of the seat cover around the seatbelt area by again lining up the seams of the seat cover to the seams of the seat.



Step 18. Driver & Passenger Top/DT&PT:

Tuck the seat covers in on the left and right sides, lining up the seams on the sides. The side loop Velcro™ is shown inside out, but not tucked in



Step 19. Driver & Passenger Top/DT&PT:

If you're not able to get Step 7. to release the seat from the back wall of the truck, this step will be the trickiest part of installing the seat cover tops. Carefully tuck the hook Velcro™ into the seat. Lift the seat bottom partway up, and with one hand holding the side loop Velcro™ inside out (see step 14) use the other hand to wrap the long hook Velcro™ around to the side, pinning it to the seat, and then press the side loop Velcro™ to it by pushing your hand in between the seats, which will un-fold the side, and connecting the Velcro™.

Now, carefully move the seat bottom up and down to make sure the seat action is not being impeded. Move, or re-position the Velcro™ to tighten, or to free up the seats action.



Step 20. Armrest/A:

Slide the armrest cover on with the extending hook Velcro™ to the front. Feed the armrest pull strap through the provided opening and carefully tuck the material under the plastic starting on one side, then the other. Fold the armrest down, and tuck in the hook Velcro™ under the front of the armrest.



Step 21. Armrest/A:
Carefully tuck the front left and right sides in, pull the hook Velcro™ through to the back as shown.



Step 22. Armrest/A:
Pull the material up flush, then with one hand, pin the hook Velcro™ to the armrest, fold the loop Velcro™ over the back of the armrest, connecting the Velcro™.



Step 23. Headrests/H:
Slide the cover on with the extending hook Velcro™ to the front, connecting them to the loop Velcro™ sewn inside the back edge.

Congratulations, you're done!!!