

2010-2016 Ranger 60-40 Installation Instructions



Step 1. Headrests/H:

All the parts of the seat cover are labeled on the inside right corners of the seat cover. Use the seat cover part ID chart to identify part numbers. Turn the hook Velcro™ inside out on the back of the headrest covers and slide it down into position.



Step 2. Headrests/H:

Center the headrest cover, aligning the seams of the seat cover to the seams of the seat, they should match closely.



Step 3. Headrests/H:

Recline the backrests and temporarily remove the headrests by depressing both push button releases and gently lifting up. The right side release is easily seen by the pointer finger, the other one by the pinky is slightly hidden.



Step 4. Headrests/H:

Pull the four extending hook Velcro™ from the front around to the back side and press them into the carpet on the back of the headrest.



Step 5. Headrests/H:

Then, stick the backside hook Velcro™ to the carpet and set the headrest aside for later installation.



Step 6. Driver & Passenger Top/DT&PT:

As done with the headrest cover, turn the backside hook Velcro™ inside out while sliding the seat cover down over the backrest.



Step 7. Driver & Passenger Top/DT&PT:
Tuck the fabric of the seat cover under the plastic for the headrests, starting with the push button side first.



Step 8. Driver & Passenger Top/DT&PT:
Manipulate the material inside the seat cover from thumb to forefinger on top and down both front sides. As in Step 2, align the seams of the seat cover left and right to the seams of the seat, they should closely match.



Step 9. Driver & Passenger Top/DT&PT:
Manipulate the fabric inside the seat cover from thumb to forefinger around the backside corners.



Step 10. Driver & Passenger Top/DT&PT:
Tuck the front edge hook Velcro™ into the seat and fold the seat forward.



Step 11. Driver & Passenger Top/DT&PT:
Use one hand in a smoothing action down the front of the seat cover while pulling gently on the hook Velcro™ from behind, then press it onto the carpet. Look at the front side and see if the Velcro™ needs to be tightened, or moved left or right for best fit.



Step 12. Driver & Passenger Top/DT&PT:
Pull down and press the back edge Velcro™ onto the carpet on the seat back starting in the middle and work your way out.



Step 13. Console/C:

With the console up, slide the cover on and tuck the fabric in around the hinge area.



Step 14. Console/C:

Slide the rear Velcro™ in next to the hinge and connect them to the long front Velcro™. Re-tighten the Velcro™ if needed to make sure they're really tight.



Step 15. Console/C:

Tightly connect these two side to side Velcro™ in front.



Step 16. Console/C:

Dry fit the remaining Velcro™ by laying them into the box. Clean those areas with rubbing alcohol by scrubbing hard then wiping dry while it's still wet.



Step 17. Lid/L:

With the console down, open all the Velcro™ and place the lid cover on with the letter "L" to the back.



Step 18. Lid/L:

Open the lid up and connect the Velcro™ underneath starting with the front to back ones first (or top to bottom as seen in the picture), then the side to side Velcro™. Re-tighten Velcro™ as needed for best fit.