

# 2007-2014 Jeep Wrangler Buckets Installation



### Step 1. Headrest/H:

All the parts of the seat cover are identified by abbreviations on the inside front right side of each piece. Use the seat cover part ID chart to identify the different parts and pieces. Slide the headrest covers on with the extending hook (sticky) Velcro™ to the front.



### Step 2. Headrest/H:

Temporarily remove the headrests by lifting them up all the way, depress the push button releases while holding gentle upward pressure.



### Step 3. Headrest/H:

Line up the seams of the headrest cover to the seams of the headrest, they should closely match. Tuck the front Velcro™ under the back edge and connect it as shown.



### Step 4. Driver & Passenger Top/DT&PT:

Temporarily remove the keep pin from the backside of the recline handle by pushing up with both fingers alongside the shaft. Use your other hand over the top of the handle to keep the pin from flying away on you.



**Step 5. Driver & Passenger Top/DT&PT:**  
View of keeper pin.



**Step 6. Driver & Passenger Top/DT&PT:**  
Slide the pin back over the handle and set it aside.



**Step 7. Driver & Passenger Bottoms/DB&PB:**  
Place the cover on with the long Velcro™ to the front.



**Step 8. Driver & Passenger Bottoms/DB&PB:**  
Work the material of the seat cover from thumb to forefinger, aligning the seams as in Step 3.



**Step 9. Driver & Passenger Bottoms/DB&PB:**  
Route the under the knee Velcro™ above the wiring.



**Step 10. Driver & Passenger Bottoms/DB&PB:**  
Connect them to the carpet on the back edge, or if no carpet exists connect them to the loop Velcro™ sewn on the back edge.





**Step 11. Driver Bottom/DB:**  
Connect the Velcro™ under the side lever.



**Step 12. Driver & Passenger Bottoms/DB&PB:**  
Route the side hook Velcro™ over the seat slides.



**Step 13. Driver & Passenger Bottoms/DB&PB:**  
Route the far back side Velcro™ where shown, above the seat slide in back.



**Step 14. Driver & Passenger Bottoms/DB&PB:**  
The side Velcro™ should be fastened in an "X" pattern.



**Step 15. Driver & Passenger Bottoms/DB&PB:**  
Pull the back edge of the cover back hard and connect it to the carpet on the back edge of the seat. Skip this step if no carpet exists on the seat. If no carpet exists, snap the two buckles under the seat and press them to the loop Velcro™ sewn on the back edge.



**Step 16. Driver & Passenger Tops/DT&PT:**  
Slide the cover on with the extending hook Velcro™ to the front.





**Step 17. Driver & Passenger Tops/DT&PT:**  
Tuck the fabric under the plastic for the headrests.



**Step 18. Driver & Passenger Tops/DT&PT:**  
Tuck the front edge in.



**Step 19. Driver & Passenger Tops/DT&PT:**  
Pull the Velcro™ thru to the back.



**Step 20. Driver & Passenger Tops/DT&PT:**  
Use one hand in a smoothing action down the front of the cover from top to bottom while pulling on the Velcro™ from the back, tuck it under and connect it to the loop Velcro™ sewn inside the back edge.



**Step 21. Driver & Passenger Tops/DT&PT:**  
Position the hole for the recline lever and press it back onto the seat.



**Step 22. Driver & Passenger Tops/DT&PT:**  
Fold this small side hook Velcro™ around the backside and connect it to the carpet on the backside.



**Step 23. Driver & Passenger Tops/DT&PT:**  
Same as Step 22, fold the Velcro™ around the back and connect it to the carpet behind the panel.



**Step 24. Lid/L:**  
Slide the lid cover with the "L" marked inside to the back. Note: 2007-2010 does not include a cover for the lid.



**Step 25. Lid/L:**  
Connect the Velcro™ under the rear hinge. Note: 2007-2010 does not include a cover for the lid.



**Step 26. Lid/L:**  
Connect the side to side Velcro™ in front, then pull the front Velcro™ back and connect them to the side to side Velcro™ shown. Note: 2007-2010 does not include a cover for the lid.