2013-2022 Dodge Leather 40-20-40 Installation



Step 1.

Prepare the driver and passenger seat for installation by temporarily removing the headrests. Recline the backrests and depress the two push button releases shown while holding gentle upward pressure.





(View from under the back of the seat bottom.) Use your electric controls to lift the seat up all the way, and move it forward. Temporarily unhook both plastic pieces sewn to the elastic straps by pushing them forward. Use caution reaching under the seat and avoid sharp metal edges.



Step 3. Remove the seat belt from the elastic on the inside edge of the driver and passenger seat bottoms.



Step 4. Driver & Passenger Bottoms/DB&PB: All the parts of the seat cover are labeled inside. Use the Seat Cover Piece Identification Chart to ID parts. Tuck the back edge of the seat cover into the seat. Next, route the long hook (sticky) fasteners under the front of the seat where shown, avoiding any seat mechanisms.



Step 5. Driver & Passenger Bottoms/DB&PB: Slide the long outside edge hook fasteners in as shown between the plastic and the seat, then put the seat belts through the elastic on the inside of the cover.



Step 6. Driver & Passenger Bottoms/DB&PB: Line up the seams of the seat cover to the seams of the seat, they should match closely. Then, tuck the outside edge in as shown.





Step 7. Driver & Passenger Bottoms/DB&PB: Mate the long front edge hook fasteners to the loop fastener sewn on the back edge. Route the outside edge hook fastener at an angle and mate it to the loop fastener sewn on the back edge. Use one hand in a smoothing action from front to back along the outside edge and top of the seat cover while pulling on the back of the seat cover, then tightening the fasteners.

Step 8. Driver & Passenger Bottoms/DB&PB: View from the inside edge of the passenger bottom. Mate the two hook fasteners sewn inside the seat cover to the carpet on the seat. Like step 7, slide one hand from front to back along the inside edge while mating the fasteners to the carpet to remove any slack in the seat cover.



Step 9. Driver & Passenger Bottoms/DB&PB: Connect the plastic hooks under the back edge of the seat to the metal bar, and then mate hook fasteners to the loop fastener as in Step 7. This will keep the seat cover from shifting around. Trim off the excess length of fasteners.



Step 10. Driver & Passenger Top/DT&PT: Slide the seat covers on with the extending hook fasteners to the front. Tuck the fabric under the plastic on the outside edge of the seat. Like Step 6, line up the seams of the seat cover to the seams of the seat.



Step 11. Driver & Passenger Top/DT&PT: Tuck the fabric under the plastic of the headrests starting with the push button side as shown.



Step 12. Driver & Passenger Top/DT&PT: Tuck the hook fasteners into the seat, slide the seat forward and tip the backrests forward.



Step 13. Driver & Passenger Top/DT&PT: View from under the back of the seats. Route the long hook Velcro[™] on left and right, over the metal rod that runs front to back. Note: the Velcro[™] will get crinkled when it's run over the bar and tightened. Feed the center Velcro[™] over the metal rod.



Step 15. Driver & Passenger Top/DT&PT: Center the backside of the seat cover and mate the hook fasteners on the seat cover to the carpet on the back of the seat. Lastly, re-connect the plastic clips under the seat.



Step 14. Driver & Passenger Top/DT&PT: Use one hand in a smoothing action down the front of the seat, pull the fabric down in back and hold it to the seat while you pull the Velcro[™] forward over the bar, then bring it back and connect the Velcro[™] as shown. It might take a couple tries before you get it tight.



Step 16. Middle Bottom Back/MBB: Lift the middle bottom up and place the loop Velcro[™] into the cavity of the middle bottom. Prepare the surface of the plastic with rubbing alcohol. Press the adhesive hook Velcro[™] to the inside of the plastic box.



Step 17. Middle Bottom Back/MBB: Mate the hook Velcro[™] to the carpet on the back edge of the middle seat bottom by tucking behind the vent



Step 18. Middle Bottom/MB: Connect the Velcro[™] to the carpet on the bottom of the seat and then the middle Velcro[™] to each other.



Step 19. Console/C: Slide the cover on as shown, line up the seams.



Step 20. Console/C: Tuck the left & right front in around the hinge area



Step 21. Console/C: Pull the back left & right sides up and press the Velcro[™] to the carpet as shown.



Step 22. Console/C: Pull the back left & right sides up and press the Velcro[™] to the carpet as shown.



Step 23. Console/C: Slide the rear Velcro[™] into the hinge area using a sawing motion while moving the lid. Fold the Velcro[™] into the cavity and look where they will lay inside. Clean the areas with rubbing alcohol by scrubbing hard and wiping it dry while it's still wet. Pull the Velcro[™] tight, peel off the backing and press the adhesive Velcro[™] onto the plastic.





Carefully open the Velcro[™] and fold the console down, place the cover on and open the lid. Line up the seams and connect the Velcro[™] under the lid as shown.



Step 25. Headrests/H: Slide the cover on with the headrest still on the seat with the extending Velcro™ to the front as shown.



Step 26. Headrests/H: Tuck the front Velcro[™] under the back edge and connect it to the loop Velcro[™] sewn inside the back edge.