

2013-2024 Dodge Crew Rear 40-60 w/ armrest Installation



Step 1.

Lift the seat bottoms up and temporarily remove the headrests by depressing the push button releases simultaneously while gently lifting up until the headrest comes out. Make sure to lift the seat bottoms up to reinstall the headrests back into the seat after the installation for the tops is complete.



Step 2. Driver & Passenger Top/DT&PT:

All the parts of the seat cover are labeled inside. Use the Seat Cover Piece Identification Chart to ID parts. Carefully disconnect all of the Velcro™ on the seat cover. Place the seat cover tops on with the extending hook (sticky) Velcro™ on top.

Passenger Top: Open the armrest cavity and push the armrest through and tuck the seat cover behind the seatbelt.



Step 3. Driver & Passenger Top/DT&PT:

Lift the seat bottoms up. Fold the 2X22" hook Velcro™ that's on top of the seat in half lengthwise with the sticky facing in, making them 1X22", and stiff as a ruler. Slide them down behind the seat. You may have to fold the bottoms down slightly in order to move the bottom edge of the seat away from the back of the cab giving more clearance to grab the Velcro™.



Step 4. Passenger Top/PT:

Slide the hook Velcro™ that is behind the armrest, down in front of the seatbelt as shown. Line up the seams of the seat cover to the seams of the seat on the left, right, and armrest cavity, they should match closely. Form the top of the seat cover to the top corners of the seat on left and right, then slide your hand down the inside edge where the two seats come together in the center.



Step 5. Driver & Passenger Top/DT&PT:
 Pictured is one of the 1X12" hook Velcro™ sewn on the bottom left and right corners of the DT & PT. Tuck the fabric behind the plastic as shown on Step 6.

Pull the seat cover down around the bottom right and left corners. It's critical to get the covers pulled down all the way and over the bottom corners of the seat.



Step 6. Passenger Top/PT:
 Route the left and right 1X12" side Hook Velcro™ from Step 5 under the bottom corner around to the side of the seat (above pointer finger), connecting it to the loop (fuzzy) Velcro™ sewn inside. Some re-connecting of the side Velcro™ may be necessary to provide the best fit. Do this by sliding your hand down the sides of the seat cover, pull the bottom corner under the seat back, then take up the slack and re-connect the Velcro™.



Step 7. Passenger Top/PT:
 Reach up behind the seat and feel for the long hook Velcro™ from Step 3, and pull them down. Slide your hand down the front of the seat gathering up slack. Pull the seat cover all the way to the back edge of the seat (under the seat), connecting the hook Velcro™ to the loop (fuzzy) Velcro™ sewn inside the front edge.



Step 8. Driver & Passenger Top/DT&PT:
 Tuck the armrest cavity fabric under the front of the armrest and behind the hinge area, and fold the armrest down. Pull the hook Velcro™ up from behind the armrest.



Step 9. Driver & Passenger Top/DT&PT:
 Push the fabric into the top of the cavity with one hand, and then mate the loop Velcro™ in back by pressing it down onto the hook Velcro™ behind the armrest with the other hand.



Step 10. Armrest/A:
 Slide the cover on with the cut-out on the top, and extending hook Velcro™ to the front. Tuck it under the front of the drink holders, then the back.



Step 11. Armrest/A:
 Pull the hook Velcro™ up from the back and mate them to the loop Velcro™ sewn inside the back edge.



Step 12. Headrests/H:
 Slide the covers on with the extending hook Velcro™ to the front. Line up the seams, and connect the Velcro™ as shown.



Step 13. Driver & Passenger Bottoms/DB&PB:
 Tilt the seat bottom up, and slide the seat covers on with the letters "DB" & "PB" up.



Step 14. Driver & Passenger Bottoms/DB&PB:
 Work the fabric from the seams inside the cover to the middle (pointer finger), and line up the seams.



Step 15. Driver & Passenger Bottoms/DB&PB:
Tuck the top part of the seat cover in. 2011-2016 model seat covers will have a series 1"X3" Hook Velcro™ on the top part that connects to the carpet under the seat bottoms.



Step 16. Driver & Passenger Bottoms/DB&PB:
Lastly, press the hook Velcro™ to the carpet on the seat, starting on one side moving to the other.