

# 2014-2019 Chevy/GMC Buckets Installation



## Step 1. Headrests/H:

**This Installation is on our YouTube Channel. The Link is <https://youtu.be/GyQelDB8CqI>**

Only difference between 2014-16 models and the 2017 is the 2017 headrests remove differently, follow Step 2. All the parts of the seat cover are labeled inside. Use the seat cover part ID chart to ID parts. Slide the headrest covers on with the extending Velcro™ to the front.



## Step 2. Headrests/H:

Tuck the Velcro™ under the back edge and press them together. Recline the backrests and temporarily remove the headrests by depressing the push button release on the one side, and lift the headrest all the way up. Then, push a small allen wrench or heavy wire into the hole in the plastic on the other post (Right hand) while gently lifting up until the headrest releases. If you are having trouble removing them, call 877-485-3001.



## Step 3. Driver & Passenger seat preparation.

First release the back panel from behind the seats. Feel under the back edge of the seat on each side for the elastic straps. They are connected to support wires under the seat with the plastic clips shown in the picture (side view). They're fairly difficult to remove. Pry the plastic clip open while pushing it forward. I used my fingers to pry it open, but you may opt for a tool of some sort to pry it open. For 2014, and some 2015's, put tape along the bottom edge of the back panel, it's very sharp. You'll be removing the tape after Step 17. 2015-2016 Models do not have the sharp plastic panel.



## Step 4. Driver & Passenger Bottom/DB&PB:

Place the seat cover on with the extending hook Velcro™ to the front. Tuck the seat cover behind the plastic cowl on the outside edge. For electric seat controls, lift the seat all the way up and move it forward. Line up the seams of the seat cover to the seams on the seat around the outside edge, they should match closely.



**Step 5. Driver & Passenger Bottom/DB&PB:**  
Work the fabric from the seam inside the seat cover outwards, or from forefinger to thumb.



**Step 6. Driver & Passenger Bottom/DB&PB:**  
Tuck the back edge in. Be very careful, the bottom of the flap has a very sharp edge on it. Use caution when reaching under the seat. The metal is sharp, and all moving parts have grease on them. Check your hands every time they come from under the seat, keep a rag handy.



**Step 7. Driver & Passenger Bottom/DB&PB:**  
Electric seats, lift the seat up all the way. Fold the all of the front edge and outside edge Velcro™ in half lengthwise with the hook facing in. This will stiffen Velcro™ and make it easier to route under the seat. Look under the front of the seat and poke the Velcro™ straight thru to the back.



**Step 8. Driver & Passenger Bottom/DB&PB:**  
Likewise with the left and right side Velcro™, fold them in half lengthwise. Push the outside edge Velcro™ straight down where shown.



**Step 9. Driver & Passenger Bottom/DB&PB:**

Feel for the outside edge Velcro™ in the gap shown, pull it back and press it to the loop Velcro™ sewn on the back edge.



**Step 10. Driver & Passenger Bottom/DB&PB:**

Likewise for the inside edge Velcro™. Push it down thru the gap shown and route it to the back edge and press it to the rear loop Velcro™. Note, some repositioning of the Velcro™ may be needed to accommodate the Velcro™ of the seat cover top.



**Step 11. Driver & Passenger Bottom/DB&PB:**

Snap the plastic clip over the metal support wire under the back edge of the seat where shown, and press the hook Velcro™ to the loop Velcro™ sewn on the back edge. This will keep the seat cover from shifting around. Carefully trim the excess Velcro™



**Step 12. Driver & Passenger Top/DT&PT:**

**Provisions are made for the side impact airbags. It is critical to get the covers on the correct side.**

The covers are marked on the inside front right “DT & PT” for Driver & Passenger Tops. Also note, the Driver Top has our Headwaters Seat Cover label on the backside.

Slide the seat cover on with the extending hook Velcro™ to the front as shown. Again, line up the seams of the seat cover to the seams of the seat, they should match closely.



**Step 13. Driver & Passenger Top/DT&PT:**  
Tuck the seat cover under the plastic for the headrests, starting on the push button side.



**Step 14. Driver & Passenger Top/DT&PT:**  
Tuck the front edge of the seat cover in.



**Step 15. Driver & Passenger Top/DT&PT:**  
While pulling on the seat cover from behind, right where the Velcro™ is sewn on, slide one hand down the front side of the seat in a smoothing action taking up the slack. Make sure you're backrest are positioned slightly forward from normal. When the seat cover is fully installed, recline the backrests to the normal positions, it'll help tighten the front side even more.



**Step 16. Driver & Passenger Top/DT&PT:**  
Route each of the long hook Velcro™ under the back edge of the seat and around the outside support wire, the same area the plastic clip connected to. Take up the slack again as in Step 15, then reach under the seat and take up the slack in the Velcro™ by pulling it forward and connect as shown in Step 17. Then press the seat cover with one hand to the seat while taking up the slack in the Velcro™ with the other hand.



**Step 17. Driver & Passenger Top/DT&PT:**  
Press the Velcro™ together, trim the excess. Next re-connect the plastic clips to the metal bar. Hold the clip in position with one hand, then pull back on the elastic with the other hand and it'll clip back on.



**Step 18. Driver & Passenger Top/DT&PT:**  
Pull the backside down and press the hook Velcro™ onto the carpet on the backside of the seat.



**Step 19. Lid/L:**  
Carefully disconnect the Velcro™ on the lid with it upside down in your hands, keeping the Velcro™ separated. Working from the back seat area on your knees, flip it over and place the lid cover on with all the Velcro™ hanging all around the outside as shown.



**Step 20. Lid/L:**  
Hold the cover on with one hand, open the lid and use your body to hold the lid cover in place. First, connect the top to bottom Velcro™. Make sure they both run along the outside edge, right next to the plastic extrusion that sticks out as shown. Connect the remaining Velcro™ under the lid as shown. You'll need to re-connect and tighten the Velcro™ to get the cover to fit tight. Finished install should look like the picture.