

# 2019-2024 RAM Crew 40-60 W/ Opening Console Installation



## Step 1. DH/PH: Driver and Passenger Headrests

All our pieces are marked on the inside of the cover to show where they belong. Headrest Covers are marked DH (Driver Headrest) & PH (Passenger Headrest) inside. Push an Allen wrench or a wire into the hole on the plastic, then depress the push button release for the other headrest post while gently lifting up evenly.



## Step 2. DH/PH: Driver and Passenger Headrests

Push the button on the side to flip the headrest forward.



## Step 3. DH/PH: Driver and Passenger Headrests

Slide the headrest covers on with the extending hook Velcro™ to the front. Tuck the material under the plastic button shown. Line up the seams of the cover to the seams on your headrest, they should match closely. Lastly, connect the Velcro on the back of the headrest.



## Step 4. Prep:

Release the seatbelts from the elastic as shown.



## Step 5. DT: Driver Top

Carefully disconnect the Velcro™, and place the cover on with the long Hook Velcro™ on top. Carefully tuck the cover under the plastic for the headrests starting with the push button release as shown.



## Step 6. DT: Driver Top

Form the cover to the top of the seat and on left and right. Again, line up the seams of the seat cover to the seams on your seat, they should match closely.



**Step 7. DT: Driver Top**  
Tuck the cover in on left and right as shown.



**Step 8. DT: Driver Top**  
Tuck in the front edge, along with the 1"x14" hook Velcro™ sewn on left and right.



**Step 9. DT: Driver Top**  
Locate the Hook Velcro™ front the front side and pull them down. Next, pull the seat cover down forcibly, tightening the front of the seat cover.



**Step 10. DT: Driver Top**  
Route the 1X14 Hook Velcro™ around to the sides of the seat, connecting them to the Loop Velcro™ sewn inside the sides.



**Step 11. DT: Driver Top**  
Lifting the seat bottoms up will pull the top of the seat away from the cab allowing room to route the Velcro™. Fold the 2"x24" Hook Velcro™ in half lengthwise with the sticky facing in. Now it'll be 1"x24" and rigid. Push the Velcro™ straight down.



**Step 12. DT: Driver Top**  
Reach up behind the seat and feel for the Velcro™ from the top. Pull the down and connect them to the Loop Velcro™ sewn inside the front edge of the seat cover.





**Step 13. PT: Passenger Top**  
Pull the shoulder seatbelt out of the way.



**Step 14. PT: Passenger Top**  
Pull the cover over the seat starting with the metal peg that the console latches to.



**Step 15. PT: Passenger Top**  
Tuck the front of the cover under the seat as shown.



**Step 16. PT: Passenger Top**  
Tuck the top part under the console.



**Step 17. PT: Passenger Top**  
With the seat bottom partway up, tuck in the front edge of the seat cover.



**Step 18. PT: Passenger Top**  
Now, fold the console down and look behind it. You'll find a magnetic carpeted flap. Pop the flap off and fold it back.



**Step 19. PT: Passenger Top**

View from under the seat. Connect the Hook Velcro™ that was tucked in between the seats to the Loop Velcro™ sewn inside the piece you tucked under the console. Install the rest of the Passenger Top same as Steps 5-12 for the Driver Top.



**Step 20. DB/PB: Driver and Passenger Bottoms**

Flip the seat bottom up and slide the cover on with the extending Hook Velcro™ on top.



**Step 21. DB/PB: Driver and Passenger Bottoms**

Use a toothless butter knife to tuck the fabric behind the plastic as shown.



**Step 22. DB/PB: Driver and Passenger Bottoms**

Fold the seat down and tuck the cover in.



**Step 23. DB/PB: Driver and Passenger Bottoms**

Flip the seat bottom up and pull the Hook Velcro™ through. Starting on one side moving to the other, press the Hook Velcro™ to the carpet under the seat.



**Step 24. DB/PB: Driver and Passenger Bottoms**

With the seat up, tuck the cover under the top of the plastic as shown





**Step 25. DB/PB: Driver and Passenger Bottoms**  
Press the Hook Velcro™ sewn inside the seat cover to the carpet under the seat.



**Step 26. DB/PB: Driver and Passenger Bottoms**  
We replaced the factory elastic for the seatbelts by our own on the seat cover.



**Step 27. DB/PB: Driver and Passenger Bottoms**  
Slide the seatbelts back into the elastic.



**Step 28. C: Console**  
Fold the console forward slightly and pull the cover over the top.



**Step 29. C: Console**  
Locate the console release strap and feed it through the provided opening.



**Step 30. C: Console**  
Tuck the cover under the front of the console as shown using the same toothless butter knife.





**Step 31. C: Console**

Tuck the front in, and fold the console down. Take the magnetic carpeted flap (from Step 18) And lay it across the top of your console, take the extending Velcro from the front, pull tight and press the Velcro™ onto the bottom of the magnetic flap.



**Step 32. C: Console**

Lift the console up, and route the side Velcro™ in between the plastic where shown. The Velcro™ will be pointing to the back. The other Velcro™ just wraps around the corner to the back.



**Step 33. C: Console**

Tuck the cover under the plastic using the toothless butter knife where shown.



**Step 34. C: Console**

Angle both Velcro™ to the center and press them to the magnetic carpeted flap. Reconnect the magnetic carpeted flap back onto the back of the cab.



**Step 35. L: Lid**

Carefully disconnect the Velcro™ on the Lid cover. Place the cover on with the letter "L" printed on the inside to the back. Once pulled into place, use one hand to hold the Lid cover on, then flip it up.



**Step 36. L: Lid**

Connect the Velcro™ under the lid as shown, starting with the top to bottom, then the sides. You can pull hard on the Velcro™, ensuring a tight fit.