## **2019-2024 Ram 40/20/40 Dip Top w/ Opening Consoles**



Step 1. Headrests/H:

The installation can be viewed on our YouTube channel: https://youtu.be/-qg1-LKyl7Q
All the parts of your seat cover are labeled on the inside right of each part. Use the seat cover Part ID chart for identification.

Carefully open the Velcro<sup>™</sup> and slide the headrest cover on with the extending hook Velcro<sup>™</sup> to the front in a side to side sawing motion as shown.



Step 2. Headrests/H:

Recline the seats so the headrest will clear the roof while removing it.

Release the headrests by gently lifting them up all the way. Then, depress the two buttons at the same time while holding gentle upward pressure, lifting evenly until it comes out.



Step 3. Headrests/H: (Steps 3 & 4 Only Apply to the large variant of the "Thick Headrest")

Carefully open the Velcro on bottom and side of the cover. Slide the cover on with the extending hook Velcro to the front.



Step 4. Headrests/H:

Connect the side Velcro™ as shown.



Step 5. Headrests/H:

Line up the seams of the headrest cover to the seams of the headrest on left and right, they should match closely.

Lastly, connect the Velcro<sup>™</sup> on the back edge as shown.



**Step 6. Seat Preparation:** 

View from behind the seat. Slide the seats all the way forward. For electric controlled seats, lift seats up all the way up. Prepare the seat for installation by releasing the elastic shown in hand. There are two on each seat, note the location and avoid covering with Velcro™ installing the seat bottoms.



**Step 7. Seat Preparation** 

Follow the elastic under the seat to where it's connected, push it forward to unclip it.



**Step 8. Seat Preparation** 

Next, locate the metal bar at the back edge of the seat. This bar is super sharp on top and bottom and capable cutting your seat cover.



**Step 9. Seat Preparation:** 

Cover the top and bottom edge with electrical tape, or use 2" wide tape and do in one shot.



Step 10. Seat Preparation

Carefully press the tape to the metal bar.



Step 11. Driver & Passenger Top/DT&PT: Provisions are made for the side impact airbags. It is critical to get the covers on the correct side.

The covers are marked on the inside front right "DT & PT" for Driver & Passenger Top. Also note, the Driver Top has our Headwaters Seat Cover label on the backside.

Slide the DT & PT on, tucking the fabric under the plastic for the headrests, starting on the push button side as shown.



Step 12. Driver & Passenger Top/DT&PT:

Form the top of the seat cover to the top of the seat. Next, line up the seams of the seat cover to the seams of the seat on left and right, they should match closely.



Step 13. Driver & Passenger Top/DT&PT:

Tuck in the outsides of the seat cover behind the plastic molding as shown.



Step 14. Driver & Passenger Top/DT&PT:

Next, pull down and carefully tuck the cover under the taped metal bar shown in Step 15.

Next, line up the seams of the seat cover to the seams of the seat on left and right, they should match closely.



Step 15. Driver & Passenger Top/DT&PT:

Pull the material tight with both hands. Then use one hand in a smoothing action down the front of the seat cover from top to bottom, while pulling on the cover from behind the seat with the other hand to gain slack on the front side.



Step 16. Driver & Passenger Top/DT&PT:

Next, carefully wrap the material around the metal bar.



**Step 17. Driver & Passenger Top/DT&PT:**Start on one side. Hold the material tight with one hand.



**Step 18. Driver & Passenger Top/DT&PT:**Press the provided "pinch welt" over the material onto the metal bar.



Step 19. Driver & Passenger Top/DT&PT:
Pull the other side tight and connect same as Step 16.
Look at the front side and see if the cover is fitting snug.
If not, repeat Step 15 to snug the cover.



**Step 20. Driver & Passenger Bottom/DB&PB:** View of driver seat next to the console. Remove the seat belt from the elastic as shown.



Step 21. Driver & Passenger Bottom/DB&PB:
Place the cover on with the long hook Velcro™ to the
front as shown. Use caution working under the seat. All
the metal is razor sharp, and anything that moves has
grease. Look at your hands before touching the seat
cover after working under the seat to avoid getting
grease on to your seat cover. Keep a paper towel or rag
handy.



**Step 22. Driver & Passenger Bottom/DB&PB:**Tuck the back edge in carefully under the metal bar.
From behind, pull the cover back and tight to the front of the seat as shown on Step 23.



Step 23. Driver & Passenger Bottom/DB&PB: Same as Step 12, line up the seams of the seat cover to the seams of the seat along the sides and front. Work the material inside the cover outward, or from forefinger to thumb.



Step 24. Driver & Passenger Bottom/DB&PB:
Again, for electric controlled seats, lift the seat/seats all the way up. This clears a path to route the Velcro™.
Fold the side Velcro™ in half lengthwise as shown, with the sticky facing in. This will make it stiff and easier to route.



Step 25. Driver & Passenger Bottom/DB&PB: Slide the side Velcro™ straight down from where it's sewn on.



Step 26. Driver & Passenger Bottom/DB&PB:
Use a light when working under the seat.
Locate the side Velcro™, and route it thru the gap in the frame to the back corner, avoid wires.
Similar to Step 15, slide your hand down the outside edge of the cover while gently pulling on the Velcro™, then press it to the loop Velcro™ sewn on the back edge as shown. Be careful to not over tighten and create wrinkles.



**Step 27. Driver & Passenger Bottom/DB&PB:**Same as Step 24, fold the long front of the seat hook Velcro™ in half lengthwise with the sticky facing in.



Step 28. Driver & Passenger Bottom/DB&PB:
Route the outside front Velcro™ where shown to the back, avoiding any mechanisms or wiring. Temporarily connect it to the loop Velcro™ sewn on the back edge.



**Step 29. Driver & Passenger Bottom/DB&PB:**Same as Step 28, route the front Velcro<sup>™</sup> where shown, avoiding the mechanisms and wiring.



Step 30. Driver & Passenger Bottom/DB&PB: Connect the two plastic buckles under the backside of the seat to the frame. Position them left and right, centered with about 6-8" between them.



Similar to Step 15, use one hand in a smoothing action from front to back on the seat bottom while pulling on the back of the cover with the other hand. This will gain slack and tighten the cover to the front of the seat.

Lastly, press the hook Velcro™ to the loop Velcro™ sewn on the back edge. Trim the excess length of Velcro™.



**Step 32. Middle Bottom/MB:**Same as in previous steps, line up the seams of the seat cover to the seams of the seat.



Step 33. Middle Bottom/MB:
Connect the long front and short side hook Velcro to the carpet fuzz under the bottom of the seat on the back edge, then connect the middle Velcro to each other.



With the console up, slide the cover on with the drink holders on top as shown. Form the front of the cover to the front of the console, then fold it down. The cover should be lined up with the drink holders and the base of the plastic lip for the cavity inside the console.



Step 35. Console/C:

Tuck the left and right sides behind the plastic molding, and pull the cover up into position, flush along the opening. Pull the back edge up to the hinge. Do this by using the same smoothing action in previous steps. Slide one hand down the front from top to bottom while pulling on the back edge of the console cover. Next, press the hook Velcro™ to the fuzzy carpet on the sides of the console in front and back of the hinge area as shown.



Step 36. Console/C:

Route the back edge loop Velcro™ between the lid and console next to the hinge as shown.



Step 37. Console/C:

Fold the Velcro™ into the cavity and note where they will lay inside. Clean the areas with rubbing alcohol by scrubbing hard and wiping it dry while it's still wet. Pull the Velcro™ snug, then peel off the backing and press the adhesive Velcro™ onto the plastic. If the adhesive isn't sticking, clean the areas with warm soapy water, then rubbing alcohol again.



Step 38. Lid/L:

Carefully disconnect the Velcro<sup>™</sup> and place it on the console lid. As in previous steps, line up the seams of the cover to the seams of the console lid, they should match closely. Use one hand to hold it in place, then open the console. Connect the top to bottom Velcro<sup>™</sup> first, then the sides. Pull the Velcro<sup>™</sup> forward gaining slack, then re-connect them.



Step 39. Lid/L:

Properly installed it should look like this photo.



Call 877-485-3001 for any installation questions.