

2019-2024 RAM Crew 40-60 W/ Armrest Installation



Step 1. DH/PH:

All our pieces are marked on the inside of the cover to show where they belong. These will be marked DH (Driver Headrest) & PH (Passenger Headrest). Press an allen wrench or strong piece of wire into the hole on the side of the plastic around the headrest bar and lift up.



Step 2. DH/PH:

Push the button on the side of the headrests to topple them and make them easier to pull out.

Video installation on YouTube:
<https://youtu.be/ofOYYMDLlbs>



Step 3. DH/PH:

Pull the cover over your headrests with the extending Velcro on the front of the headrest. There will be an opening provided for the push button on the side. Tuck the cover underneath the plastic as shown. Once you have the cover in place, connect the extended Velcro from the front to the Velcro on the back of the headrests.



Step 4. DT:

Lay the Driver Top out and undo all the Velcro. Take the cover and place in onto the backrest with the 2 small headrest holes at the top.



Step 5. DT:

Push the headrest plastics through the holes provided. Be careful when doing this, being too rough with these little plastics can break them.



Step 6. DT:

Fit the cover around the corners and get the cover into position.



Step 7. DT:

Now work your way down the cover, tucking the edges around the seat. When you get to the bottom tuck the cover down through the space between the seat bottom and backrest.



Step 8. DT:

Once you have the corner Velcro's hanging down, pull down on the fabric to tighten things up. Take the bottom corner Velcro's and route them around the backside of the seat.



Step 9. DT:
Now as you're feeding it up the back and toward the outside of the seat you'll want to try and lay it flat against the back edge of the seat.



Step 10. DT:
Next, with the other hand, take the flap on the side of the seat that has some loop Velcro on it and press it against the hook Velcro that you just fed up the back.



Step 11. DT:
Take the long Velcro's at the top of the cover and feed them down the back of the seat. It might be easier if you fold the in half long ways. This stiffens them up and can make it easier to feed down.



Step 12. DT:
Once you get it the Velcro's fed down, give it a good tug. Just be cautious about how hard you pull. Don't want to snap the Velcro off.



Step 13. DT:

Next, take the Velcro's and attach it to the loop located on the inside of the cover.



Step 14. DB/PB:

Lift the seat up and pull the cover over the seat. Try a sawing motion to get it on.



Step 15. DB/PB:

Once you get it on there, now is the time to position it. Make sure you line the seams on the sides of the seat up with the seams of the cover. Using a sweeping motion over the cover is the best way to get rid of wrinkles and adjust it. Now feed the top of the cover into the space between the backrest and seat bottom.



Step 16. DB/PB:

Take the hook Velcro's extending from the top of the cover, pull tight on the material and press the Velcro's against the fuzz on the bottom of the seat.



Step 17. DB/PB:
Take the hook Velcro at the edges of the top, pull tight, and press them to the seat as well.



Step 18. DB/PB:
Now take the bottom of the cover, pull tight and press the bottom of it to the fuzz too.



Step 19. PT:
The passenger top install is very similar to the driver side, with the main difference being an armrest. Place the cover onto the backrest. As you are placing it on push the seat's armrest through the hole provided. Now follow steps #5-#13 and install the whole cover before starting with the armrest area.



Step 20. PT:
Now tuck the Velcro under the armrest into the encasement area behind the armrest.



Step 21. PT:

Lay the arm down and grab the recently tucked Velcro. Pull tight and connect them to the loop Velcro that is located on the flap shown above.



Step 22. A:

Slip the armrest cover over the arm. Make sure the opening is on the same side as the drink holders. Before you get the cover pulled tight find the pull tab at the front of your arm and push it through a provided opening at the very front of the cover. Then finish pushing the cover on.



Step 23. A:

Similar to the encasement from before, take the bottom of the arm cover and feed it through to the back of the arm. Then, take the top flap and connect the bottom with the top.



Step 24. Congrats!

You have installed your covers!