2001-03 F-150 Crew Cab Rear 60-40 Installation



Step 1. Driver & passenger Top:

Tip the backrests forward and temporarily remove the headrests by depressing the push button release and gently lifting the headrests up evenly.



Step 2. Driver and Passenger Top/DT&PT:

Slide the seat cover with the extending hook (sticky) $Velcro^{TM}$ to the front.



Step 3. Driver and Passenger Top/DT&PT:

Tuck the fabric under the plastic for the headrests, starting with the push button side first.



Step 4. Driver and Passenger Top/DT&PT:

Form the top of the seat cover to the top of the seat. Line up the seams of the seat cover to the seams of your seat, they should match closely.



Step 5. Driver and Passenger Top/DT&PT:

Tuck the front left and right front sides in as shown.



Step 6. Driver and Passenger Top/DT&PT:

Press the hook Velcro™ onto the carpet on the back of the seat. Do it by using one hand in a smoothing action down the front of the seat from top to bottom, removing slack and tightening the seat cover.



Step 7. Driver and Passenger Top/DT&PT:
Pull the back edge down and press the hook Velcro™
to the carpet on the seat back.



Step 8. Driver and Passenger Bottom/DB&PB:
Place the seat covers on with the long extending hook
Velcro™ to the front. Line up the seams of the seat
cover as in Step 4.



Step 9. Driver Bottom/DB: Feed the seat belts through he provided opening.



Step 10. Driver and Passenger Bottom/DB&PB: Tuck the back edge of the seat cover in.



Step 11. Driver and Passenger Bottom/DB&PB:
Press the extending hook Velcro™ to the back edge of
the seat as shown. The side hook Velcro's cross in the
back at roughly a 45 degree angle. The long front
Velcro's fasten straight back.



Step 12. Driver and Passenger Bottom/DB&PB: Pull the back edge of the seat cover back and press it to the carpet on the back edge. Using one hand in a smoothing action from front to back helps remove the slack and tighten the cover.



Step 13. Headrests/H:

Slide the cover over one side with the extending hook Velcro™ to the front and the loop Velcro™ in back.



Step 14. Headrests/H:

Compress the headrest and slide the other side all the way down. The headrest foam will spring back into shape once the cover is pulled all the way down.



Step 15. Headrests/H:

Work the material inside the cover outward, from thumb to forefinger around the sides.



Step 16. Headrests/H:

Tuck the Velcro under the back edge, keeping it tight, then press the loop $Velcro^{TM}$ to it.



Step 17. Driver and Passenger Cargo Flaps/DCF&PCF:

Slide the covers on with the bottom of the cover turned inside out so the hook $Velcro^{TM}$ doesn't stop it from being pulled down onto position.



Step 18. Driver and Passenger Cargo Flaps/DCF&PCF:

Press the Velcro[™] to the carpet on the cargo flap.