

2011-16 F-250-350 Super Crew Rear 60/40 Installation



Step 1. Driver and Passenger Tops:

Temporarily remove the headrests. Do this by first lifting the headrests up all the way using the visible plastic push button release. Hold gentle upward pressure and simultaneously depress the visible release button and the hidden release button on the other plastic piece until the headrest releases.



Step 2. Driver and Passenger Tops:

Driver's side; Tilt the armrest forward and slide the seat cover with the extending hook (sticky) Velcro™ to the front.

Passenger side; Slide the seat cover on with the extending hook Velcro™ to the front



Step 3. Driver and Passenger Tops:

Tuck the fabric of the seat cover under the plastic for the headrests.



Step 4. Driver and Passenger Tops:

Fold the backrest forward and mate the Velcro™ below the seat release levers on the outside edge of each backrest.



Step 5. Driver and Passenger Tops:
Line up the seams of the seat cover with the seams of your seat along the left and right sides of each backrest, they should closely match. Tuck the hook fasteners into the seat and fold the backrest down. Mate the hook Velcro™ to the loop (fuzzy) Velcro™ sewn inside the back edge working from one side to the other.



Step 6. Headrests:
Slide the headrest covers on when the headrest is on the seat, with the extending hook Velcro™ to the front. Line up the seams on left and right and mate the fasteners in back as shown.



Step 11. Driver and Passenger Bottoms:
Remove the seat belts from the elastic straps. Using the side release lever, lift the seat bottoms partway up. Slide the seat cover on with the extending hook Velcro™ up and line up the seams.



Step 12. Driver and Passenger Bottoms:
Lift the seat bottom up. Mate the hook Velcro™ to the carpet on the underside of the seat starting with the extending hook Velcro™ on top, then the bottom. Place the seat belts thru the seat cover's elastic. Finally, make sure the hole for the seat locker is lined up, if it has them.