

2005-13 Tundra Extended Cab 40-60 Rear Installation



Step 1. Headrest removal:
Lift the headrests all the way up, then depress the push button release and remove the headrests.



Step 2. Top/T:
All the parts of the seat cover are labeled inside. Use the Seat Cover Piece Identification Chart to ID parts. Fold the armrest down and slide the seat covers over the seat.



Step 3. Top/T:
Tuck the fabric under the plastic for the headrests starting with the push button side.



Step 4. Top/T:
Tuck the cover in front of the metal child restraint.



Step 5. Top/T:
Tuck the bottom of the seat cover in as shown around the seatbelts. Tuck the seat cover between the seat and the silver child restraints leaving them exposed.



Step 6. Top/T:
Tuck the cover into the seat, avoiding the armrest bracket. Line up the seams of the seat cover to the seams on the seat, they should match closely.




Step 7. Top/T:

Tuck the corners of the seat in and form them to the sides, then tuck the Velcro™ into the seat on the left and right front corners.



Step 8. Top/T:

Route the side hook Velcro™ straight up behind the plastic for the seat release lever, pull it tight, then connect it to the loop Velcro™ sewn on the side of the cover as shown.



Step 9. Driver & Passenger Bottoms/DB&PB:

Tilt the seat bottoms up, Compress the seat and slide the seat covers on with the extending Velcro™ to the front/top side. It will be tight, but go slow and ease it down, once halfway down it gets easier.



Step 10. Driver & Passenger Bottoms/DB&PB:

Tuck the cover behind the plastic as shown



Step 11. Driver & Passenger Bottoms/DB&PB:

Form the inside corners to the seat.



Step 12. Driver & Passenger Bottoms/DB&PB:

Connect the Velcro™ as shown.



Step 13. Armrest/A:

Slide the cover on with the big opening on top. Like the seat bottoms, it will be tight going on until the halfway point.



Step 14. Armrest/A:

Tuck the pull tab from the armrest through the provided opening.



Step 15. Armrest/A:

Tuck the cover behind the plastic of the armrest hinge.



Step 16. Armrest/A:

Tuck the front of the armrest in, and fold it down.



Step 17. Armrest/A:

Feed the extending hook Velcro™ through the gap on the left and right side, connecting the Velcro™ in back.



Step 18. Headrests:

Slide the covers on with the extending hook Velcro™ to the front, connecting them to the loop Velcro™ inside the back edge.