

## 2007-09 Chevy/GMC 40/20/40 w/ Opening Consoles Installation



**Step 1. Driver and Passenger Tops/DT&PT:**  
Recline the backrests slightly and temporarily remove the headrests. Do this by wedging your left hand between the seat and the headrests holding gentle upward pressure and depress the push button release. Insert a heavy weight paper clip into the hole in other plastic piece with your right hand and lift up until the headrest releases.



**Step 2. Driver and Passenger Tops/DT&PT:**  
Slide the seat covers on with the long hook straps to the front. Notice how the seat compresses at its widest point. All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts.



**Step 3. Driver and Passenger Tops/DT&PT:**  
The seat relaxes once the seat cover is pulled into position.



**Step 4. Driver and Passenger Tops/DT&PT:**  
Tuck the fabric of the seat cover under the plastic for the headrests.



**Step 5. Driver and Passenger Tops/DT&PT:**  
Work the material from the seam inside the cover from the main body of the seat cover (fingers) to the middle (thumb). Do this for the front and back of the seat cover top.



**Step 6. Driver and Passenger Tops: /DT&PT**  
Tuck the hook straps into the seat and mate them to the loop strip sewn inside the back edge. Do this by sliding one hand down the front of the seat cover and push the hook straps through as shown. Pull on the fabric (not the fastener) from behind the seat with one hand and use the other hand in a smoothing action from top to bottom. Be careful to not over-tighten the straps and indent the foam on the backrest.



**Step 7. Driver and Passenger Bottoms/DB&PB:**  
Place the seat covers on with the long hook straps to the front.



**Step 8. Driver and Passenger Bottoms/DB&PB:**  
Tuck the seat cover behind the plastic cowling.



**Step 9. Driver and Passenger Bottoms/DB&PB:**  
Tuck the back edge of the seat cover into the seat.  
Pull it into position from behind the seat.



**Step 10. Driver and Passenger Bottoms/DB&PB:**  
Tuck the seat cover in behind the plastic on the inside back edge.



**Step 11. Driver and Passenger Bottoms/DB&PB:**  
Route the three long hook straps in front under the seat and mate them to the loop strip sewn on the back edge.



**Step 12. Driver and Passenger Bottoms/DB&PB:**  
Feed the long outside edge hook strap between the seat and the plastic. Carefully feel under the seat for the strap in a gap between the seat slide and the seat frame. The seat slides have grease on them so clean your hands after doing this part.



**Step 13. Driver and Passenger Bottoms/DB&PB:**  
Tuck the seat cover behind the plastic on the outside edge.



**Step 14. Driver and Passenger Bottoms/DB&PB:**  
Tuck the inside long hook strap down in between the seats. Feel for it under the seat and mate it at an angle to the rear loop strip. Mate the outside edge strap the same.



**Step 15. Driver and Passenger Bottoms/DB&PB:**  
Connect the two plastic hooks under the back of the seat to the frame and mate the hook fastener to the rear loop strip. This will keep the seat cover from sliding forward.



**Step 16. Middle Bottom/MB:**  
Mate the hook fastener to the carpet on one side in front.



**Step 17. Middle Bottom/MB:**  
Mate the hook fastener on the same side to the carpet.



**Step 18. Middle Bottom/MB:**  
Continue working your way around the cover mating the fasteners.



**Step 19. Console/C:**

With the console in the up position place the cover on with the opening for the drink holders on top. Pull it down into place with the console in the up position.



**Step 20. Console/C:**

Tuck the seat cover behind the plastic on the left and right.



**Step 21. Console/C:**

Pull the hook fasteners on the left and right around to the back and mate them to the loop strip sewn inside the back edge.



**Step 22. Console/C:**

Note the areas where the fasteners will lay inside of the console. Clean the areas with rubbing alcohol, wiping them dry while the alcohol is still wet. If they are not sticking, stop and re-clean the areas. Do not use any auto detailing protectant before applying the adhesive hook, it will not adhere. Mate the loop straps to the adhesive hook inside the plastic box.



**Step 23 Lid/L:**

Place the cover on with the lid closed. Feed the long straps through the hinge and mate them to the straps in front. Clean these areas same as step 21. Mate the loop tabs to the adhesive hook.



**Step 24. Headrests/H:**

Slide the cover on with the extending hook fasteners to the front, mating them to the loop fastener in back.