

## 1988-1991 Chevy/GMC 40-60 split bench



### Step 1. Driver & Passenger Top/DT&PT:

All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts. Slide the seat cover on with the extending hook (sticky) Velcro™ to the front. Line up the seams of the seat cover to the seams of your seat, they should closely match. Use a smoothing action from top to bottom with one hand, tucking the hook Velcro™ into the seat and mate them to the loop Velcro™ sewn inside the back edge.



### Step 2. Driver & Passenger Bottom/DB&PB:

Slide the seat forward all the way and place the cover on with the long hook Velcro™ to the front. Tuck the back edge in and like the backrests, the seams should closely line up. Pull on the seat cover from behind the seat with one hand, smoothing with the other hand from front to back. Route the long hooks Velcro™ under the seat, above the tension springs and seat adjustment wires, pressing them to the loop Velcro™ sewn on the back edge.



### Step 3. Driver & Passenger Bottom/DB&PB:

View from behind the driver seat. Slide the seat forward and tilt backrest ahead. Tuck the inside part of the seat cover between the driver and passenger seats. Pull the material around to the back with one hand and smooth the side of the seat cover with the other hand from front to back. Fasten the upper hook Velcro™ to the rear loop strip first, and then the lower Velcro™. Keep re-adjusting the seat cover and Velcro™ for the best fit.



### Step 4. Driver & Passenger Bottom/DB&PB:

View from the driver bottom outside edge. Slide the seat into your position for driving. Route the long outside hook Velcro™ through the opening in the seat frame as shown towards the back edge. Make sure to not interfere with any seat adjustment wires or tension springs. Connect it to the rear loop Velcro™ at an angle for the best fit. Route the long inside hook Velcro™ around the back corner and connect it to the rear loop Velcro™ at the best angle. Now, slide the seat forward and back, it should move easily back and forth. If a Velcro™ is hanging up, re-route it, or if you don't move your seats much, don't worry about it.



**Step 5. Driver & Passenger Bottom/DB&PB:**  
Hook one "no slip" strap under the back of the seat to the frame where each person sits, then mate it to the rear loop Velcro™.



**Congratulations!** With the seat cover installed properly the seat cover will not move and should last for several years.