

1988-94 Toyota 60-40 Installation



Step 1. Driver and Passenger Tops/DT & PT:

The pieces of the seat cover are labeled inside. Use The "Seat Cover Piece Identification Chart" to identify the different pieces of the seat cover. Temporarily remove the headrests by gently lifting up and depress the push button release.



Step 2. Driver and Passenger Tops:

Slide the seat cover on with the extending hook (sticky) Velcro™ to the front. Tuck the fabric under the plastic for the headrests starting with the push button side. Line up the seams of the seat cover to the seams of your seat, they should closely match.



Step 3. Driver Top/DT:

Recline the backrest. View of the left side of the armrest. Tuck the fabric past the hinge.



Step 4. Driver Top:

Tuck the fabric in on the right side. Tuck the back piece of fabric in behind the armrest.



Step 5. Driver Top:

Form the material into the back and top of the armrest cavity, and then fold the armrest into the seat. Pull the Velcro™ free from under the armrest.



Step 6. Driver and Passenger Tops:

Tuck all of the extending hook Velcro™ into the seat and tip the backrest forward.



Step 7. Driver and Passenger Tops:

Gently pull on the Velcro™ from behind the seat with one hand. Then, use the other hand in a smoothing action to remove slack in front of the seat from top to bottom connecting the hook Velcro™ to the loop (fuzzy) Velcro™ sewn inside the back edge. Start on the inside edge of the seat working your way out. This may take more than one try.



Step 8. Driver Bottom/DB:

Place the seat cover on with the extending hook Velcro™ to the front. Feed the seatbelt through the provided opening. Tuck the back edge of the seat cover into the seat. Route the long hook Velcro™ in front of the seat, under the seat and connect them to the loop Velcro™ sewn on the back edge.



Step 9. Driver Bottom:

Work the fabric inside the seat cover out (from forefinger to thumb).



Step 10. Driver Bottom:

Pull the inside edge hook Velcro™ around to the back and press it to the loop Velcro™ on the back edge.



Step 11. Driver Bottom:

Route the outside edge hook Velcro™ where shown, feel for it under the seat and connect it to the rear loop Velcro™.



Step 12. Driver Bottom:

Snap this hook under the back of the seat to one of the wires that support the seat foam and connect it to the rear loop Velcro™. This will keep the seat cover from shifting around. Trim the excess length of Velcro™ with a scissors.



Step 13. Passenger Bottom/PB:

Like the drivers bottom, place the seat cover on with the long hook Velcro™ to the front and tuck the material in. Route the long front hook Velcro™ under the seat and connect them to the rear loop Velcro™.



Step 14. Passenger Bottom:

Push the seat away from the plastic and slide the outside edge hook Velcro™ in where shown. Feel for it under the seat and press it to the loop Velcro™ in back.



Step 15. Passenger Bottom:

Route the inside edge Velcro™ the same way as in step 14.



Step 16. Armrest/A:

Recline the driver's backrest. Slide the armrest cover on with the extending hook Velcro™ to the front.



Step 17. Armrest:

Tuck the hook Velcro™ into the seat and connect them to the loop Velcro™ sewn inside the back edge.



Step 18. Headrests:

Slide the cover on with the extending hook Velcro™ to the front. Connect them to the loop Velcro™ in back.