

1994-1998 DODGE SLT 40-20-40 Installation Instructions



Step 1. Driver and Passenger Bottoms/DB&PB:
All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts.
Place the seat cover on with the long hook (sticky) Velcro™ to the front as shown.



Step 2. Driver and Passenger Bottoms/DB&PB:
Pull the outside piece of material back, line up the hole for the recline lever. For models with electric controls for the driver. Loosen the screws in the electric panel, then tuck the fabric behind the panel and tighten the screws.



Step 3. Driver and Passenger Bottoms/DB&PB:
Quad cab: Pull the small cap over the back corner of the seat bottom and press the hook Velcro™ in back to carpet on the back of the seat. Put the handle back on to seat.
Regular Cab: Press the hook Velcro™ to the loop Velcro™ sewn on the left and right of the back edge of the seat cover.



Step 4. Driver and Passenger Bottoms/DB&PB:
Regular cabs do not have carpet on the back edge of the seat, so a loop (fuzzy) Velcro™ is sewn on the back edge. Pull the inside flap of material around to the back and connect it to the carpet (or loop Velcro™) on the back of the seat as shown on the right side of the photo.



Step 5. Driver and Passenger Bottoms/DB&PB:
View from the right side of the driver seat under the middle seat bottom. Route the inside long side hook Velcro™ between the seat slide and the seat as shown. Notice how the Velcro™ goes in between the seat slide and the seats material. Route the outside Velcro™ the same.



Step 6. Driver and Passenger Bottoms/DB&PB:
Press the long side hook Velcro™ to the carpet crossing each other at an angle. Next, route the three long hook Velcro™ under the front of the seat, avoiding the seat wires and springs to the back and press them to the carpet (or loop Velcro™) on the seat. The outside Velcro™ feeds through the seat bracket in front. When properly attached it should look like this. Lastly, pull the back edge of the seat cover (shown in hand) back hard and mate it to the carpet of the seat (or loop Velcro™). Reposition the Velcro™ if needed to pull out any wrinkles. Use a free hand to smooth the seat cover out while pulling out the wrinkles.



Step 7. Driver and Passenger Bottoms/DB&PB:
View from under the front of the seat bottom, left side. Connect the plastic to the metal as shown, and then connect the Velcro™, trim the excess.



Step 8. Driver and Passenger Bottoms/DB&PB:
FOR REGULAR CABS WITH NO SEAT CARPET ONLY.
Clip the two plastic clips under the back edge of the seat and press them to the loop Velcro™ sewn on the back edge. This keeps the sea cover in place.



Step 9. Driver and Passenger Tops/DT&PT:

Slide the seat cover on with the extending hook Velcro™ to the front. It will be very tight going on, so work one side then the other. Work the top of the seat cover with both hands to conform it to the integral headrest.



Step 10. Driver and Passenger Tops/DT&PT:

Make sure the cover is pulled down all the way. Use your finger tips to manipulate the seams to remove any wrinkles. If wrinkles are still present, check to see that the seat cover isn't twisted. The seams of the headrest part of the seat cover should closely line up with the seams of the seat.



Step 11. Driver and Passenger Tops/DT&PT:

View from behind the driver's seat. Loosen the Phillips screw above the access lever. First, tuck seat cover behind the plastic at the top. Then, pull it down and tuck it under the plastic at the bottom. It will be a tight fit. You can carefully use a flat screwdriver as a shoe horn to help tuck it under. Carefully tighten the screw. Push the front hook Velcro™ into the seat and mate them to the loop Velcro™ sewn inside the back edge. Connect the Velcro™ by using one hand in a smoothing action down the front side of the seat cover while gently pulling on the Velcro™ from the behind, and then tuck it under, connecting the Velcro™.



Step 12. Console/C:

With the console in the up position slide the cover over the front. While holding the front with one hand, tuck the cover around the hinge area. Moving the material in a sawing motion will help in tucking it in. Now, fold the console down and pull the back edge up to meet the hinge for the lid. Then, slide the two ½"X4" loop Velcro™ in the back into the left and right side of the hinge in a sawing motion while moving the lid back and forth. Pull the material up flush with the opening. Make sure none of the seat cover material is riding up over the lip.



Step 13. Console/C:

Note the areas where the Velcro™ will lay inside. Clean the areas with rubbing alcohol and a paper towel. Do this by applying a liberal amount of rubbing alcohol to the towel and scrubbing the plastic hard and then quickly wiping it dry, don't let it air dry. Make sure the cover is positioned correctly before attaching any adhesive tabs. Peel the backing from the 1"X1" adhesive hook Velcro™, fold it inside of the cavity and press it down hard onto the plastic. All tabs should be on the inside of the plastic box and not on top. Start at the front and work your way to the back.



Step 14. Lid/L:

With the lid in the down position, position the cover with the four Velcro™ to the front and squeeze it on. Tilt the lid up and using a sawing motion slide the long Velcro™ on the back into the hinge. The picture is different than the actual lid cover. Improvements were made, removing the middle Velcro™ near the latch help it close easier.



Step 15. Middle Bottom/MB:

Slide the driver and passenger seats all the way front and tilt the backrests forward. Remove the seat belts from the factory elastic on the left and right of the middle bottom. Place the seat cover on with the long hook Velcro™ to the front.



Step 16. Middle Bottom/MB:

Feed the seat belts through the webbing sewn to the seat cover on the left and right.



Step 17. Middle Bottom/MB:

Route the long hook Velcro™ in front, under the seat and press them to the carpet (or loop Velcro™) on the back of the seat. Connect the long hook Velcro™ on the left and right side of the cover at an angle to the carpet on the back of the seat. Lastly, pull the rear part of the seat cover back and press the hook Velcro™ sewn inside of the seat cover to the carpet (or loop Velcro™) on the back edge.

Congratulations, you're done!

They take a good effort to get them on, but they will not move, and will last for several years, no matter how hard you use them.