

2001-2003 F-150 Super Cab Bucket Seat Installation



Step 1. Headrests/H:

All the parts of the seat cover are labeled inside the cover. Use the seat cover piece identification Chart to ID parts. Carefully open the bottom and back sides of the headrest cover and slide it on with the extending hook Velcro's to the front. Note: You will have to compress the headrest a lot in order to get it on.



Step 2. Headrests/H:

Temporarily remove the headrests by lifting them up all the way using the push button release on the right. Depress the right side push button and the hidden left side push button (next to pinky finger nail) while gently lifting up until it releases.



Step 3. Headrests/H:

Mate the rear left and right Velcro's in back of the headrest.



Step 4. Headrests/H:

Tuck the hook Velcro under the back edge and mate it with the loop Velcro sewn under the back edge.



Step 5. Driver & Passenger Top/DT&PT:
Carefully open the bottom and outside edge of the cover and place it on with the extending hook fasteners to the front. Tuck the seat cover under the plastic for the headrests and seat belt.



Step 6. Driver & Passenger Top/DT&PT:
Mate the Velcro behind the seat belt.



Step 7. Driver & Passenger Top/DT&PT:
Start on top and mate the side Velcro, working your way down a few inches at a time. Slight downward pressure helps to straighten out the seam.



Step 8. Driver & Passenger Top/DT&PT:
Tuck the hook Velcro into the seat and fold the backrest forward.



Step 9. Driver & Passenger Top/DT&PT:
Use one hand in a smoothing action down the front of the cover from top to bottom while gently pulling on the hook fastener in back. Pin the Velcro to the seat with the front hand (pictured) and press the loop Velcro into it with the other hand. Reconnect Velcro's for best fit.



Step 10. Driver & Passenger Bottom/DB&PB:
Slide the over on with the two long 2" wide hook Velcro's to the front. Tuck the back corner of the cover over the seat.



Step 11. Driver & Passenger Bottom/DB&PB:
Tuck the outside corner over the seat. Push the seat cushion in and route the long outside hook Velcro under the seat.



Step 12. Driver & Passenger Bottom/DB&PB:
Likewise, route the inside edge hook fastener under the seat.



Step 13. Driver & Passenger Bottom/DB&PB:
Work the fabric inside the seat cover outwards, from forefinger to thumb around the front corners.



Step 14. Driver & Passenger Bottom/DB&PB:
As in Step 9, use one hand in a smoothing action from front to back, tightening the cover, mating the Velcro to the carpet. Route and mate the long front hook Velcro's under the seat first. Then, route and mate the right and left hook Velcro's, they should cross as shown.



Step 15. Driver & Passenger Bottom/DB&PB:
Pull the rear most part of the seat cover back and mate the hook Velcro to the carpet under the seat.



Step 16. Lid/L:
Connect the Velcro under the lid as shown.