

## 2004-2008 F-150 Super Cab Bucket Seat Installation



### Step 1. Driver and Passenger Tops/DT&PT:

All the parts of your seat cover are labeled inside. Use the "Seat Cover Piece Identification Chart" to identify the different parts.

Remove the headrests by lifting them up all the way using the push button release on the right side. Next, use gentle upward pressure and depress the semi-hidden push button release on the left.



### Step 2. Driver and Passenger Tops/DT&PT:

Carefully open the seat cover top and tuck it behind the seatbelt and wrap it around the inside. Line up the seams of the seat cover to the seams of the seat, they should closely match. Next, tuck the fabric under the plastic for the headrests, then under the plastic housing for the shoulder mounted seatbelt.



### Step 3. Driver & Passenger Tops/DT&PT:

Connect the Velcro™ behind the plastic housing and tuck the fabric in.



### Step 4. Driver & Passenger Tops/DT&PT:

Using a bear hug method, press the Velcro™ at the top working your way down a few inches at time



**Step 5. Driver & Passenger Tops/DT&PT:**  
Continue working your way to the bottom. The fabric should meet with very little Velcro™ showing. Run your fingers down the seam to help the Velcro™ attach. You may have to re-connect the Velcro™ a few times to achieve the best fit.



**Step 6. Driver & Passenger Tops/DT&PT:**  
Pull the bottom inside edge (next to the console) and the outside edge down, lining up the seams. Tuck the hook Velcro™ into the seat and connect them to the loop Velcro™ sewn inside the back edge. Do this by gently pulling on the Velcro™ from behind and use your other hand in a smoothing action from top to bottom.



**Step 7. Driver & Passenger Bottoms/DB&PB:**  
View from the driver's side next to the console. Remove the seatbelt from its elastic restraint. The seatbelt will stay up without the help of the elastic.



**Step 8. Driver & Passenger Bottoms/DB&PB:**  
Place the seat cover on with the long hook (sticky) Velcro™ to the front. Again, the seams of the seat cover should closely match the seams of your seat. Work the fabric inside the seat cover around the front of the seat cover out from forefinger to thumb until you get to the dip in the seat (4" to the right of the hand). Work the material from the dip to the back in the opposite direction towards the middle of the seat.



**Step 9. Driver & Passenger Bottoms/DB&PB:**

Route the long hook Velcro™ under the seat by folding it in half lengthwise with the sticky inwards. This will stiffen the Velcro™ and make it easier to route under the seat. Avoid any seat mechanisms, in front of the metal bar, pressing them to the carpet on the back edge of the seat where shown.



**Step 10. Driver & Passenger Bottoms/DB&PB:**

View from the outside edge of the driver's seat bottom. Push the fabric and foam of the seat in and slide the long outside edge hook Velcro™ into the gap in the metal (above the shiny metal shown in the picture). Fold the Velcro™ in half lengthwise again. Carefully feel under the back of the seat for the Velcro™. You will find it below the spring in a gap in the metal. You can use a screwdriver or pencil to fish it out of the gap. This will be the most difficult part of the installation and will take a few tries. Once pulled through pull tight and press the Velcro™ to the carpet on the back of the seat.



**Step 11. Driver & Passenger Bottoms/DB&PB:**

Tuck the long inside edge hook Velcro™ down next to the middle bottom and route it through the gap between the seat and seat slide and press it to the carpet on the back edge. If it sticks to carpet on the inside edge of the seat, pull it back up and cut the Velcro™ down to 4" and press it to the carpet on the side of the seat.



**Step 12. Driver & Passenger Bottoms/DB&PB:**

Tuck the back edge of the seat cover into the seat.



**Step 13. Driver & Passenger Bottoms/DB&PB:**  
Pull back on the fabric of the seat cover and press it to the carpet on the seat working from one side to the other. You may have to re-adjust the front, left and right side, and back Velcro™ for the best fit.



**Step 14. Headrests/H:**  
Slide the cover on with the headrest still on the seat and the hook Velcro™ to the front. You will have to compress the headrest to get it on. The headrest will relax once pulled all the way down.



**Step 15. Headrests/H:**  
Connect the hook Velcro™ to the loop Velcro™ sewn inside the back edge as shown.



**Step 16. Lid/L:**  
Place the lid cover on as shown with the "L" marked inside to the back. Connect the Velcro™ under the lid. Re-connect the Velcro™ for the best fit.