

2007-2014 Yukon 40/20/40 w/ Opening Consoles Installation



Step 1. Driver and Passenger Tops/DT&PT:
Recline the backrests slightly and temporarily remove the headrests. Wedge one hand between the seat and the headrest and hold gentle upward pressure and depress the push button release, simultaneously insert a piece of stiff wire (small diameter coat hanger works well or heavy paper clip) into the hole in other plastic piece with your right hand and lift up until the headrest releases.



Step 2. Driver and Passenger Tops/DT&PT:
Slide the seat covers on with the long hook (sticky) Velcro™ to the front. Notice how the seat compresses at its widest point. All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts.



Step 3. Driver and Passenger Tops/DT&PT:
The seat relaxes once the seat cover is pulled into position.



Step 4. Driver and Passenger Tops/DT&PT:
Tuck the fabric of the seat cover under the plastic for the headrests.



Step 5. Driver and Passenger Tops/DT&PT:
Work the material from the seam inside the cover from the main body of the seat cover (fingers) to the middle (thumb). Do this for the front and back of the seat cover top. Align the seams of the seat cover to the seams of the seat, they should match closely.



Step 6. Driver and Passenger Tops: /DT&PT
Tuck the hook Velcro™ into the seat and mate them to the loop Velcro™ inside the back edge. Do this by sliding one hand down the front of the seat cover and push the hook Velcro™ through as shown. Pull on the Velcro™ from behind the seat with one hand and use the other hand in a smoothing action from top to bottom.



Step 7. Driver and Passenger Bottoms/DB&PB:
Place the seat covers on with the long hook Velcro™ to the front.



Step 8. Driver and Passenger Bottoms/DB&PB:
Tuck the seat cover behind the plastic cowling.



Step 9. Driver and Passenger Bottoms/DB&PB:
Tuck the back edge of the seat cover into the seat. Pull it into position from behind the seat.



Step 10. Driver and Passenger Bottoms/DB&PB:
Tuck the seat cover in behind the plastic on the inside back edge.



Step 11. Driver and Passenger Bottoms/DB&PB:
If you have electric seats be sure to lift the seat up as high as it will go. This will pull everything away from your seat and free up some space. Route the three long hook Velcro™ in front under the seat and mate them to the loop Velcro™ sewn on the back edge. The moving metal parts under the seat have grease on them so check your hands for grease. Keep a rag handy for steps 11-15.



Step 12. Driver and Passenger Bottoms/DB&PB:
Feed the long outside edge hook Velcro™ between the seat and the plastic. Feel for it under the seat, pull it tight and connect it at an angle to the loop Velcro™ on the back edge of the seat cover.



Step 13. Driver and Passenger Bottoms/DB&PB:
Tuck the seat cover behind the plastic on the outside edge. Align the seams of the seat cover to the seams of the seat, they should match closely.



Step 14. Driver and Passenger Bottoms/DB&PB:
Tuck the inside long hook Velcro™ down in between the seats. Feel for it under the seat, pull it tight and connect it at an angle to the loop Velcro™ on the back edge of the seat cover.



Step 15. Driver and Passenger Bottoms/DB&PB:
Connect the plastic hooks under the back of the seat to the metal bar that supports the foam (about 2" in). Connect the hook Velcro™ to the rear loop Velcro™. This will keep the seat cover from sliding around.



Step 16. Middle Bottom/MB:
Press the hook Velcro™ to the carpet on one side in front. Align the seams of the seat cover to the seams of the seat, they should match closely.



Step 17. Middle Bottom/MB:
Press the hook Velcro™ on the same side to the carpet.



Step 18. Middle Bottom/MB:
Continue working your way around the cover connecting the Velcro™.



Step 19. Console/C:

With the console in the up position place the cover on with the opening for the drink holders on top. Pull it down into place with the console in the up position.



Step 20. Console/C:

Tuck the seat cover behind the plastic on the left and right. Align the seams of the seat cover to the seams of the seat, they should match closely.



Step 21. Console/C:

Pull the hook Velcro™ on the left and right around to the back and connect them to the loop Velcro™ sewn inside the back edge.



Step 22. Console/C:

Note the areas where the Velcro™ will lay inside of the console. Clean the areas with rubbing alcohol, wiping them dry while the alcohol is still wet. If they are not sticking, stop and re-clean the areas. Do not use any auto detailing protectant before applying the adhesive hook Velcro™, it will not adhere. Connect the loop Velcro™ to the adhesive hook Velcro™.



Step 23 Lid/L:

Place the cover on with the lid closed. Feed the long Velcro™ through the hinge and mate them to the straps in front. Clean these areas same as step 21. Mate the loop Velcro™ to the adhesive hook Velcro™.



Step 24. Headrests/H:

Slide the cover on with the headrest on the seat. Align the seams of the seat cover to the seams of the seat, they should match closely. Slide the cover on with the extending hook Velcro™ to the front, connecting to the Velcro™ in back.