

# 2011-2016 F-250-350 Bucket Seat Installation



## Step 1. Headrest/H

All parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts. With the headrests in the down position, slide the headrest covers on with the extending hook (sticky) Velcro™ to the front.



## Step 2. Headrest/H

Release the headrests by gently lifting up, and depress the two push button releases. The pointer finger shows the visible release button, the pinky finger shows the location of the hidden button.



## Step 3. Headrest/H

Align the covers left and right, lining up the seams of the seat covers to the seams of the seat, they should match closely. Then, tuck the hook Velcro™ inside the back edge and mate them to the loop (fuzzy) Velcro™ sewn inside the back edge.



## Step 4. Driver & Passenger Top/DT&PT

Slide the seat covers on with the extending hook Velcro™ to the front. Tuck the seat cover under the plastic for the headrests starting with the push button side as shown.



## Step 5. Driver & Passenger Top/DT&PT

Work the seat cover fabric inside the seat cover from thumb to forefinger. Line up the seams of the seat cover to the seams of the seat as in Step 3.



## Step 6. Driver & Passenger Top/DT&PT

Tuck the seat cover behind the plastic on the outside edge.





**Step 7. Driver & Passenger Top/DT&PT**  
Tuck the hook Velcro™ into the seat, and fold the backrest forward.



**Step 8. Driver & Passenger Top/DT&PT**  
Use one hand in a smoothing action down the front of the seat cover while gently pulling on the Velcro™ from behind with the other hand. Pin the Velcro™ to the back of the seat, and press the loop Velcro™ to it. Work your way from one side to the other. Re-connect and tighten the Velcro™ for the best fit.



**Step 9. Driver & Passenger Bottoms/DB&PB**  
Electric seat controls, lift seat up and move forward.  
Place the covers on with the long hook Velcro™ to the front. Tuck the seat cover behind the plastic on the outside front corners.



**Step 10. Driver & Passenger Bottoms/DB&PB**  
Work the fabric inside the seat cover from forefinger to thumb, or outward, line up the seams like Step 3.



**Step 11. Driver & Passenger Bottoms/DB&PB**  
Tuck in the back edge of the seat cover.



**Step 12. Driver & Passenger Bottoms/DB&PB**  
Tuck the long outside edge Velcro™ in where shown.





**Step 13. Driver & Passenger Bottoms/DB&PB**  
Feel for the Velcro™ under the plastic and slide it free.



**Step 14. Driver & Passenger Bottoms/DB&PB**  
Route the Velcro™ around the back corner of the seat and press it to the carpet on the back edge of the seat.



**Step 15. Driver & Passenger Bottoms/DB&PB**  
Pull the inside edge next to the console around to the back and press it to the carpet on the seat. You may have to release the side Velcro™ from the carpet in order to get it back. Next, route the long side Velcro™ in front of the seatbelt next to the console by folding it in half lengthwise and poking it thru. Do not put your fingers under the seat while poking it thru, this is the sharpest area under the seat. Look for it behind the seat and carefully grab it, connect same as Step 14.



**Step 16. Driver & Passenger Bottoms/DB&PB**  
Route the long front Velcro™ under the seat as shown, above the metal framework. Do this by folding them in half lengthwise with the sticky facing in. It'll stiffen them up so your able to poke them thru all the way to the back.



**Step 17. Driver & Passenger Bottoms/DB&PB**  
Pull back and press the Velcro™ to the carpet on the back edge of the seat.



**Step 18. Driver & Passenger Bottoms/DB&PB**  
Pull the rear part of the seat cover back while using one hand in a smoothing action from front to back and press it to the carpet on the seat.



**Step 19. Lid/L**

Place the lid cover on with the letter "L" marked inside to the back. Connect the front to back Velcro™ first, and then the side to side Velcro™.