

1999-2004 F-150 Ext Cab Rear 40-60/Bench Installation



Step 1. Top/T

All the parts of the seat cover are labeled inside. Use the seat cover piece identification chart to ID parts. Remove the backrest by pushing in the plastic tabs on left and right while lifting up.



Step 2. Top/T

This is the slot where you push the tab in. Using a tool to push the plastic in will save wear and tear on your fingers.



Step 3. Top/T

Slide the seat cover on with the extending hook (sticky) Velcro™ to the bottom. Connect the Velcro™ to the top of the seat.



Step 4. Top/T

Press the side hook Velcro™ to the carpet on the side of the seat.



Step 5. Passenger Bottom/PB
Temporarily remove the seat belt from the elastic.



Step 6. Driver & Passenger Bottom/DB & PB:
Slide the covers on with the extending hook Velcro™ to the top side, pressing them to the carpet as shown.



Step 7. Driver & Passenger Bottom/DB & PB:
Work the fabric to the middle from the seams. From thumb to forefinger.



Step 8. Driver & Passenger Bottom/DB & PB:
Press the hook Velcro™ on the bottom side to the carpet as shown.